




Zeus²

Operator Manual

ENGLISH



Preface

Disclaimer

As Navico is continuously improving this product, we retain the right to make changes to the product at any time which may not be reflected in this version of the manual. Please contact your nearest distributor if you require any further assistance.

It is the owner's sole responsibility to install and use the equipment in a manner that will not cause accidents, personal injury or property damage. The user of this product is solely responsible for observing safe boating practices.

NAVICO HOLDING AS AND ITS SUBSIDIARIES, BRANCHES AND AFFILIATES DISCLAIM ALL LIABILITY FOR ANY USE OF THIS PRODUCT IN A WAY THAT MAY CAUSE ACCIDENTS, DAMAGE OR THAT MAY VIOLATE THE LAW.

Governing Language: This statement, any instruction manuals, user guides and other information relating to the product (Documentation) may be translated to, or has been translated from, another language (Translation). In the event of any conflict between any Translation of the Documentation, the English language version of the Documentation will be the official version of the Documentation.

This manual represents the product as at the time of printing. Navico Holding AS and its subsidiaries, branches and affiliates reserve the right to make changes to specifications without notice.

Trademarks

Lowrance[®] and Navico[®] are registered trademarks of Navico.

Fishing Hot Spots[®] is a registered trademark of Fishing Hot Spots Inc. Copyright© 2012 Fishing Hot Spots.

Navionics[®] is a registered trademark of Navionics, Inc.

NMEA 2000[®] is a registered trademark of the National Marine Electronics Association.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Additional mapping data: Copyright© 2012 NSI, Inc.: Copyright© 2012 by Richardson's Maptech.

Copyright

Copyright © 2014 Navico Holding AS.

Warranty

The warranty card is supplied as a separate document.

In case of any queries, refer to the brand website of your display or system:

bandg.com

Regulatory statements

This equipment is intended for use in international waters as well as coastal sea areas administered by countries of the E.U. and E.E.A.

The Zeus² complies with:

- CE under R&TTE directive 1999/5/EC
- The requirements of level 2 devices of the Radiocommunications (Electromagnetic Compatibility) standard 2008.

The relevant Declaration of conformity is available in the Zeus² section on the following website: bandg.com.

About this manual

This manual is a reference guide for operating the Zeus² systems. It assumes that all equipment is installed and configured, and that the system is ready to use.

The manual assumes that the user has basic knowledge of navigation, nautical terminology and practices.

Important text that requires special attention from the reader is emphasized as follows:


→ **Note:** Used to draw the reader's attention to a comment or some important information.

⚠ **Warning:** Used when it is necessary to warn personnel that they should proceed carefully to prevent risk of injury and/or damage to equipment/personnel.

Viewing the manual on the Zeus² screen

The pdf viewer included in the Zeus² makes it possible to read the manuals and other pdf files on the unit. Manuals can be downloaded from bandg.com.

The manuals can be read from an inserted Micro-SD card or copied to the unit's internal memory.



Use the menu options or the keys and on-screen buttons to maneuver in the pdf file as described below:

Search, Goto page, Page Up and Page Down	Select the relevant panel button
Scroll pages	Turn the rotary knob.
Panning on the page	Drag finger on the screen in any direction.
Zoom In/Out	Use pinch or spread gestures.
Exit the pdf viewer	Press the X key or select the X in the upper right corner of the panel.

The software

This manual is written for the Zeus² software version 1.5.

The manual will be continuously updated to match new software releases. The latest available manual version can be downloaded from bandg.com.

Contents

9	Introduction
9	The front panel and keys
10	The Home page
11	Application pages
12	Integration of 3 rd party devices
13	GoFree™ wireless
13	H5000 integration
13	Remote controllers
14	Basic operation
14	Turning the unit on and off
14	Display illumination
14	Locking the touch screen
15	Touch screen operation
16	Using menus and dialogs
16	Selecting pages and panels
17	Positioning a Man Over Board mark
17	Screen capture
18	Customizing your system
18	Customizing the Home page background
18	Adjusting panel size
19	Adding new favorite pages
19	Edit favorite pages
19	Setting the appearance of the Instrument bar
20	Charts
20	The Chart panel
21	Chart data
21	Showing dual chart types
21	Vessel symbol
21	Chart scale
21	Panning the chart
22	Positioning the vessel on the chart panel
22	Displaying information about chart items
23	Using the cursor on the chart panel
23	Saving waypoints
23	Creating routes
23	Measuring distance
24	Find objects on chart panels
24	3D charts
24	Chart overlay
25	Insight specific chart options
25	Insight view options
25	Navionics specific chart options
26	Navionics chart settings
26	Navionics view options
28	Jeppesen tides and currents
29	Chart settings
31	Waypoints, routes and tracks
31	Waypoints
32	Routes
35	Tracks
36	Waypoints, routes and tracks dialogs

37	Navigating
37	Navigate to cursor position
37	Navigate a route
37	Navigating with the autopilot
38	Navigation settings
40	The SailSteer panel
41	Selecting data fields for the SailSteer panel
41	Sail Time calculations
42	Time and Wind plots
42	The Time plot panel
42	Wind Plot panel
43	Autopilot
43	Safe operation with the autopilot
43	Activating the autopilot
43	Switching from automatic mode to manual steering
43	Autopilot indication on the pages
45	The Autopilot panel
45	Mode overview
46	Standby mode
46	Non-Follow Up (NFU, Power steering)
46	Follow-up steering (FU)
46	AUTO mode (auto compass)
47	NoDrift mode
47	NAV mode
48	WIND mode
49	WIND Nav mode
50	Turn pattern steering
51	Using the Zeus ² in an AP24/AP28 system
52	Using the autopilot in an EVC system
52	Autopilot settings
55	Radar
55	The radar panel
55	Radar overlay
56	Radar operational modes
56	Radar Range
56	Using the cursor on a radar panel
56	Saving waypoints
57	Adjusting the radar image
58	Advanced radar options
58	Radar view options
59	EBL/VRM markers
60	Setting a guard zone around your vessel
61	MARPA targets
62	Recording radar data
62	Radar settings
64	Echosounder
64	The Echosounder image
65	Zooming an Echosounder image
65	Using the cursor on the echosounder panel
66	Saving waypoints
66	Viewing sounder history
66	Setting up the Echosounder image
67	Advanced Echosounder options


67	Recording echosounder data
68	Echosounder view options
69	Echosounder settings
71	StructureScan™
71	The StructureScan™ image
71	Zooming the StructureScan image
72	Using the cursor on the StructureScan™ panel
72	Saving waypoints
72	Viewing StructureScan™ history
73	Setting up the StructureScan image
73	Advanced StructureScan settings
75	StructureMap
75	The StructureMap image
75	Activating Structure overlay
75	StructureMap sources
76	StructureMap tips
76	Recording StructureScan data
76	Using StructureMap with mapping cards
77	Structure options
78	AIS
78	AIS target symbols
79	Viewing information about AIS targets
80	Calling an AIS vessel from the Zeus ²
80	AIS SART
81	Vessel alarms
82	Vessel settings
84	Instrument panels
84	Dashboards
84	Customizing the Instrument panel
85	Audio
85	Enabling audio
86	The Audio panel
87	Setting up the audio system
88	Operating the audio system
88	Favourite channels
88	Using Sirius radio (North America only)
89	Weather
89	Wind barbs
89	GRIB weather
91	SiriusXM™ weather
95	Video
95	The Video panel
95	Setting up the video panel
96	FLIR camera control
98	Alarms
98	Alarm system
98	Type of messages
98	Single alarms
98	Multiple alarms
99	Acknowledging a message

99	Alarms dialog
100 Tools	
100	Waypoints/routes/tracks
100	Tides
100	Alarms
100	Settings
100	Vessels
100	Sun/Moon
100	Trip calculator
100	Files
101	Find
102 Simulator	
102	Demo mode
102	Simulator source files
103	Advanced simulator settings
104 Maintenance	
104	Preventive maintenance
104	Cleaning the display unit
104	Cleaning the media port door
104	Checking the keys
104	Checking the connectors
105	NMEA 0183 Data logging
105	Software upgrades
106	Backing up your system data

1

Introduction

The front panel and keys




Key	Description
1	Touch screen
2	Power key Press once to display the System control dialog. Repeat short presses to cycle the backlight brightness. Press and hold to turn the unit ON/OFF.
3	Rotary knob Rotate to scroll through menu items, then press to confirm a selection. Rotate to adjust a value. Rotate to zoom a zoomable panel.
4	STBY / AUTO key With the autopilot in any automatic mode: Press to set the autopilot to Standby mode. With the autopilot in Standby mode: Press to display the autopilot mode selection pop-up.
5	Home key Press once to activate the Home page. Repeat short presses to cycle the favorite buttons. Press and hold to display the Favorite panel as an overlay on active page. Repeat short presses to cycle the favorite buttons.
6	X key Press once to exit a dialog, to return to previous menu level and to remove the cursor from the panel.
7	MARK key With cursor active on the panel: Press to immediately save a waypoint at cursor position. With no active cursor: Press to immediately save a waypoint at vessel position. Press and hold to display the Plot menu used for saving new waypoints, routes and tracks.
8	Card reader door
9	Micro-SD Card readers

→ **Note:** The MARK key is not available on 7" units.


The Home page

The **Home** page is accessed from any operation by a short press on the **Home** key.



Key	Description
1	Applications Select a button to display the application as a full page panel. Press and hold a button to display pre-configured split page options for the application.
2	Tools Select a button to access dialogs used for carrying out a task, or for browsing stored information.
3	Close button Select to exit the Home page and return to the previous active page.
4	Favorites Select a button to display the panel combination. Press and hold a favorite button to enter edit mode for the Favorites panel.
5	Man Over Board (MOB) button Select to save a Man Over Board (MOB) marker at the current vessel position.

Application pages



Each application connected to the system is presented on panels. The application can be presented as a full page, or in combination with other panels in a multiple panel page. All pages are accessed from the Home page.

Key	Description
1	Application panel
2	Instrument bar Navigation and sensor information. The bar can be tuned off and it can be configured by the user.
3	System Control dialog Quick access to basic system settings. Display the dialog by a short press on the Power key or by swiping down from top of the screen.
4	Status bar
5	Dialog Information to or input from the user.
6	Alarm message Displayed if dangerous situations or system faults occur.
7	Menu Panel specific menu. Display the menu by selecting the MENU panel button.


Split pages

You can have several panels on one page depending on screen size:

- 7" units: 2 panels
- 9" and 12" units: 4 panels



2 panels page



3 panels page



4 panels page

All panel sizes in a split page can be adjusted.

Pre-configured split pages

Each full screen application has several pre-configured split pages, featuring the selected application combined with each of the other panels.

- **Note:** The number of split pages cannot be changed, and the pages cannot be customized or deleted.

Access a split page by pressing and holding the main panel button.



Favourite pages

All preconfigured favourite pages can be modified and deleted, and you can create your own. You can have a total of 12 favourite pages.

Integration of 3rd party devices

Several 3rd party devices can be connected to the Zeus² system. The applications are displayed on separate panels or integrated with other panels.

A device connected to the NMEA 2000 network should automatically be identified by the Zeus². If not, enable the feature from the advanced option in the System settings dialog.

The 3rd party device is operated from the Zeus² by using menus and dialogs as on other panels.

This manual does not include specific operation instructions for any 3rd party device. For features and functionality, refer to the documentation included with the 3rd party device.

FUSION-Link integration

FUSION-Link devices connected to the NMEA 2000 network can be controlled from the Zeus².

The FUSION-Link devices will appear as additional sources when using the audio function. No additional icons will be available.

Refer to "**Audio**" on page 85 for more information.

FLIR camera integration

If a FLIR camera is available on the Ethernet network, you can display the video and control the camera from the Zeus².

The FLIR camera is controlled from the Video panel, and no additional icons will appear on the Home page.

Refer to "**Video**" on page 95 for more information.


BEP CZone integration



The Zeus² system integrates with BEP's CZone system used for controlling and monitoring a distributed power system on your vessel.

The CZone icon will be available in the Tools panel on the Home page when a CZone system is available on the network.

A separate manual is provided with your CZone system. Refer to this documentation and to the Zeus² Installation manual for how to install and configure the CZone system.



CZone dashboard

When the CZone is installed and configured, an additional CZone dashboard will be added to the Instrument panels.


You switch between a panel's dashboards by selecting the left and right arrow symbols or by selecting the dashboard from the menu.

Editing a CZone dashboard

You can customize a CZone dashboard by changing the data for each of the gauges. Available editing options depend on the type of gauge and which data sources that are connected to your system.

For more information refer to *"Instrument panels"* on page 84.

GoFree™ wireless



With a WIFI-1 unit connected to the Zeus² system you can use a wireless device to remotely control the Zeus². The Zeus² is controlled from the wireless device by Apps downloaded from their relevant Application store.

→ **Note:** For security reasons, Autopilot and CZone functions cannot be controlled from a wireless device.

Installation and wiring of the WIFI-1 unit are described in the separate WIFI-1 Installation Guide. Configuration and setup are described in the Zeus² Installation manual.

Operating the Zeus² with a wireless device

When remote control is accepted, the Zeus² page will be mirrored to the wireless device. The Zeus² image includes softkeys with the same functionality as the unit. Selecting these keys works as operating the similar hard keys on the Zeus².

H5000 integration




The Zeus² system integrates with B&G's H5000 Instrument and Autopilot system.

The H5000 icon will be available in the **Tools** panel on the **Home** page when an H5000 system is available on the network.

A separate manual is provided with the H5000 system. Refer to this documentation and to the Zeus² Installation manual for how to install and configure the H5000 system.

Remote controllers



You can connect a ZC1 to the network and remotely control the Zeus².

A separate manual is included with the remote controller.

2

Basic operation

Turning the unit on and off

You turn the unit on and off by pressing and holding the **Power** key.

If the key is released before the shut-down is completed, the power off process is cancelled.

You can also turn the unit off from the **System controls** dialog. This dialog is activated by a short press on the **Power** key, or by swiping down from top of the screen.

→ **Note:** The **System controls** dialog will not display the power off option when the unit is configured as slave. Refer to details in the Zeus² Installation manual.



First time startup

The first time the unit is started and after a master reset the system will run through an automatic start-up sequence, including language setup and automatic data source selection.

You can select to interrupt this sequence and later configure the system yourself.

Standby mode

In Standby mode, the backlight for screen and keys are turned off to save power. The system will continue to run in the background.

You select Standby mode from the **System controls** dialog.

Switch from Standby mode to normal operation by a short press on the **Power** key.

Display illumination

The display backlighting can be adjusted at any time from the **System controls** dialog. You can also cycle the preset backlight levels by short presses on the **Power** key.

If a ZM monitor is plugged into the HDMI output port on a 9" or 12" unit, an additional icon will be added to the **System controls** dialog. Select this icon to control the brightness of the external monitor.

The night mode option optimizes the color palette for low light conditions.

→ **Note:** Details on the chart may be less visible when the Night mode is selected!

Locking the touch screen

You can temporarily lock the touch screen to prevent accidental operation of the system.

This feature is also useful when cleaning the screen while the unit is turned on.

When the touch lock is active you can only operate the unit from the keys.

The touch screen operation is locked from the **System controls** dialog.








You remove the lock function by a short press on the **Power** key.



Touch screen operation

Basic touch screen operation on the different panels is shown in the table below.

The panel sections later in this manual have more information about panel specific touch screen operation.

Icon	Description
	Tap to: <ul style="list-style-type: none"> • Activate a panel on a multi-panel page • Position the cursor on a panel • Select a menu and a dialog item • Toggle a checkbox option on or off • Show basic information for a selected item
	Press and hold: <ul style="list-style-type: none"> • On any panel with a cursor to activate the cursor assist feature • On a panel button to see available split screen options • On a favorite button to enter edit mode
	Scroll through a list of available options without activating any option.
	Flick to quickly scroll through e.g. the waypoint list. Tap the screen to stop the scrolling.
	Pan to position a chart or an echo image on the panel.
	Pinch to zoom out on the chart or on an image.
	Spread to zoom in on the chart or on an image.

Using menus and dialogs

Menus

You display a page menu by selecting the **MENU** button in the upper right corner of the page.

- Activate a menu item and toggle on/off a checkbox by selecting it
- Adjust a slide bar value by either:
 - dragging the slide bar
 - selecting the + or - icons

You can also operate the menus by using the rotary knob.

- Turn the knob to scroll through menu items
- Press the knob to select a highlighted item
- Turn the knob to adjust the value of a selected item

Select the **Back** menu option or the **X** key to return to the previous menu level, and then exit.

You can make the menu slide away by tapping the screen outside the menu area, or by pressing the **MENU** button. When you re-press the **MENU** button, the menu opens in the same status it had before it closed.

The status of the cursor (active vs. inactive) will change the menu options.




Chart menu - cursor not active




Chart menu - active cursor

Dialog boxes

You select entry fields and keys in a dialog box by tapping the screen or by using the rotary knob.

Numeric and alphanumeric keyboards are automatically displayed when required for entering user information in dialogs. You operate the keyboard by selecting the virtual keys, and you confirm your entry by selecting the virtual **Enter** key or by pressing the rotary knob.

A dialog is closed by saving or cancelling the entry.

A dialog can also be closed by selecting the **X** in the dialog's upper right corner or by pressing the **X** key.

Selecting pages and panels

Selecting a page

- Select a full page panel by tapping the relevant application button on the Home page
- Select a favorite page by pressing the relevant favorite button
- Select a predefined split panel by pressing and holding the relevant application icon

Select active panel

In a multiple panel page only one panel can be active at a time. You will only be able to access the page menu of an active panel.

You activate a panel by tapping it. The active panel is outlined with a border.

Positioning a Man Over Board mark

If an emergency situation should occur, you can position a Man Over Board mark at the vessel's current position by pressing the **Home** key followed by the **MOB** button on the **Home** page.

When you activate the MOB function the following actions are automatically performed:

- a MOB mark is positioned at the vessel's position
- the display switches to a zoomed chart panel, centered on the vessel's position
- the system displays navigation information back to the MOB mark

Multiple MOB marks are positioned by repeatedly pressing the **MOB** button. The vessel will continue to show navigation information to the initial MOB mark. Navigation to subsequent MOB marks will need to be done manually.

Cancel navigation

The system will continue to display navigational information towards the MOB mark until you cancel the navigation from the menu.

Delete a MOB mark


1. Select the MOB mark to activate it
2. Tap the MOB mark's pop-up or press the **Enter** key or the rotary knob to display the MOB mark dialog
3. Select the delete option in the dialog

A MOB mark can also be deleted from the menu when it is activated. See also "*Waypoints-Routes-Tracks*" on page 31.

Screen capture

Simultaneously press the **Home** and **Power** keys to take a screenshot. By default, screen captures are saved to internal memory.

Refer to "*Tools*" on page 100 for how to view and manage files.




3

Customizing your system

Customizing the Home page background

The Home page's background can be customized. You can select one of the pictures included with the system, or you can use your own picture in .jpg or .png format.


The images can be available on any location that can be seen in the files browser. When a picture is chosen as the wallpaper, it is automatically copied to the Wallpaper folder.



Adjusting panel size

You can change the panel size for an active split page. The panel size can be adjusted for both favorite pages and for predefined split pages.

1. Activate the System control dialog by pressing the **Power** key or by dragging your finger from the top of a touch screen
2. Select the adjust splits option in the dialog
3. Adjust the panel size by dragging the adjustment icon. Confirm your changes by tapping one of the panels, by pressing the rotary knob or the **Enter** key



The changes are saved to the the active favorite or split page.

Adding new favorite pages

1. Select the **New** icon in the favorite panel on the **Home** page to open the page editor dialog
2. Drag and drop page icons to set up a new page
3. Save the page layout
The display will return to the **Home** page, and the new page will be included in the list of favorite pages.

Edit favorite pages

1. Select the edit icon for a favorite icon to enter edit mode
 - Select the cancel icon to remove a page
 - Select the tools icon to display the page editor dialog
2. Add or remove panels in the page editor dialog, then save your changes
3. Press the **X** key to leave the favorite edit mode

Setting the appearance of the Instrument bar

Data sources connected to the system can be viewed in the Instrument bar.

You can configure the Instrument bar to display either one or two bars, or set it to alternate the bars automatically.

You can turn the Instrument bar off from the **System controls** dialog.

→ **Note:** This only turns the Instrument bar off for the current page.

Turning the Instrument bar on/off

1. Activate the **System controls** dialog by pressing the **Power** key or by dragging your finger from the top of the screen
2. Deactivate/activate the instrument bar icon to toggle the bar on and off.

Edit the content of the Instrument bar


1. Activate the Instrument bar by tapping it
 2. Select the **MENU** button to edit the content
 3. Select the content you want to display
- **Note:** You can configure Bar 1 for active page or for all pages except those that have a local configuration. Bar 2 can only be configured for active page.
4. Define the time period if you want the two bars to alternate automatically
 5. Select the edit option to change any of the instrument fields, followed by the field you want to change
 6. Save your changes by selecting the finish edit option in the menu.

4

Charts

The chart function displays your vessel's position relative to land and other chart objects. On the chart panel you can plan and navigate routes, place waypoints and display AIS targets. You can overlay a radar image, a StructureScan image or weather information.

The Chart panel



Key	Description	Comment
1	MOB (Man Over Board) mark	
2	Vessel with extension line	Extension line is optional
3	Waypoint with Laylines	*
4	North indicator	
5	Route	*
6	Grid lines	*
7	Track	*
8	Range rings	*
9	Chart range scale	
10	Range rings interval	Only displayed when Range rings are turned on

* Optional chart items

→ **Note:** You turn the optional images on/off individually. For more information, see "Chart settings" on page 29.

Chart data

The Zeus² is delivered with different embedded cartography depending on region.

All units will support Insight charts from Navico including Insight Genesis. The Zeus² also supports Navionics Gold, Platinum+ and Navionics+, C-MAP MAX-N/MAX-N+ by Jeppesen as well as content created by a variety of third party mapping providers in the AT5 format. For a full selection of available charts please visit insightstore.navico.com, c-map.jeppesen.com or navionics.com.

Charts are shared over the network, so only one chart card per boat is required.

- **Note:** The system will not automatically switch to embedded cartography if the SD card is removed. A low-resolution chart will be displayed until you re-insert the SD card or manually switch back to embedded cartography.

Showing dual chart types

If you have different chart types available - embedded, in the card slot or on the Ethernet - you can show two different chart types simultaneously on a page with two chart panels.

You can select a dual chart panel by pressing and holding the Chart application button on the **Home** page, or by creating a favorite page with two chart panels.

Selecting chart type

Chart type is set individually for each chart panel.

Activate one of the chart panels by tapping it, then select one of the available chart types from the chart options menu. Repeat the process for the second chart panel, and select an alternative chart type for this panel.

- **Note:** To show charts other than Navionics, Insight chart type must be selected.

If you have identical charts available - built in, in the card slot or on the Ethernet network - the system will automatically select the chart with most chart details for your displayed region.

Vessel symbol

When a GPS and a suitable heading sensor are connected to the system, the vessel symbol indicates vessel position and heading.

Without a heading sensor fitted, the vessel icon will orientate itself using COG (Course over Ground). If no GPS is available the vessel symbol will include a question mark.





Chart scale

You zoom in and out on the chart by using the zoom panel icons, the rotary knob, or by using 2 fingers to pinch (zoom out) and spread (zoom in).

Chart range scale and range rings interval (when turned on) will be shown in the lower right corner of the chart panel.

Panning the chart


You can move the chart in any direction by dragging your finger in the desired direction.

Press the **X** key or select the **Clear cursor** menu option to remove the cursor and cursor window from the panel. This will also center the chart to vessel position.


Positioning the vessel on the chart panel

Chart orientation


Several options are available for how the chart is rotated in the panel. The chart orientation symbol in the panel's upper right corner indicates the north direction.



North up



Heading up



Course up

North up

Displays the chart with north upward. Corresponds to the usual orientation of nautical charts.

Heading up

Displays the chart with the vessel's heading directed upward. Heading information is received from a compass. If heading is not available, then the COG from the GPS will be used.

Course up

Rotates the chart in the direction of the next waypoint when navigating a route or navigating to a waypoint. If not navigating the heading up orientation will be used until navigation is started.


Look ahead

Centres the chart slightly forward of your vessel so that you can maximize your view ahead.

Displaying information about chart items

When you select a chart item, a waypoint, a route or a target, basic information for the selected item will be displayed. Tap the chart item's pop-up to display all available information for that item. You can also activate the detailed information dialog from the menu.

→ **Note:** Pop-up information has to be enabled in chart settings to see basic item information.



N 26°24.311'
W 79°29.178'
5.0 m, 183 °M

Using the cursor on the chart panel

The cursor is by default not shown on the chart panel.

When you tap on the screen, the cursor will be visible and the cursor position window will be activated. When the cursor is active, the chart will not pan or rotate to follow the vessel.

Press the **X** key or select the **Clear cursor** menu option to remove the cursor and the cursor window from the panel. This will also center the chart to the vessel position.


Select the **Restore cursor** menu option to display the cursor in its previous location. The **Clear cursor/Restore cursor** are useful features for toggling between the vessel's current location and the cursor position.

GoTo cursor

You start navigating to a selected position on the image by positioning the cursor on the panel, then using the go to cursor option in the menu.

The Cursor assist function

When using a touch screen, the cursor assist function allows for fine tuning and precision placement of the cursor without covering details with your finger.



Press and hold your finger on the screen to switch the cursor symbol to a selection circle, appearing above your finger.

Without removing your finger from the screen, drag the selection circle over the desired item to display item information.

When you remove your finger from the screen the cursor reverts to normal cursor operation.

Saving waypoints

You can save a waypoint at a selected location by positioning the cursor on the panel, then selecting the new waypoint option in the menu.

If your unit has a **MARK** key, you can press this key to immediately save a waypoint. If the cursor is active the waypoint will be saved at the cursor position. If the cursor is not active the waypoint will be saved at your vessel's position.

Creating routes

You can create routes as follows on the chart panel.

1. Tap the screen to activate the cursor
2. Select **New** followed by **New route** in the menu
3. Select the position for the first route point. Tap the screen to position the first route point, and then continue tapping the screen to place the remaining route points
4. Save the route by selecting the save option in the menu


→ **Note:** See "Waypoints-Routes-Tracks" on page 31 for more information.

Measuring distance

The cursor can be used to measure the distance between your vessel and a selected position, or between 2 points on the chart panel.

1. Position the cursor on the point from where you want to measure the distance from the vessel
2. Start the measure function from the menu
 - The measuring icons will appear with a line drawn from the vessel center to the cursor position, and the distance will be listed in the cursor information window
3. You can reposition the measuring points by dragging either icon as long as the measuring the function is active

→ **Note:** The bearing will always be measured from the grey icon to the blue icon.




You can also start the measuring function without an active cursor. Both measuring icons will then initially be located at the vessel position. The grey icon will follow the vessel as the vessel moves, while the blue icon will remain at the position given when you activated the function.

You terminate the measuring function by tapping **Finish measuring** or by pressing the **X** key.

Find objects on chart panels

You can search for other vessels or various chart items from a chart panel.

Activate the cursor on the panel to search from the cursor position. If the cursor is not active the system will search for items from the vessel's position.



- **Note:** You must have a SIRIUS data package subscription to search for fueling stations and an AIS receiver connected to search for vessels.

3D charts

The 3D option provides a three dimensional graphical view of land and sea contours.

- **Note:** All chart types work in 3D mode, but without 3D cartography for the appropriate area the chart will appear flat.

When 3D chart option is selected, the Pan and the Rotate icons appear on the right side of the chart panel.

Panning the 3D chart



You can move the chart in any direction by tapping the Pan icon and then dragging your finger in the desired direction.

Press the **X** key or select the **Return to vessel** menu option to stop panning, and to center the chart to vessel position.

Controlling the view angle



You can control the view angle by tapping the Rotate icon and then dragging on the screen.

- To change the direction you are viewing, drag horizontally
- To change the tilt angle of the view, drag vertically

- **Note:** When centered on the vessel position, only the tilt angle can be adjusted. The view direction is controlled by the chart orientation setting. See "*Positioning the vessel on the chart panel*" on page 22.

Zooming a 3D chart

You zoom in and out on a 3D chart by using the zoom panel icons or the rotary knob.

Chart overlay

Radar, Structure, AIS and weather information can be displayed as overlay on your chart panel.

When an overlay is selected, the chart menu will be expanded to include basic functions for the selected overlay.


Radar, Structure, AIS and weather functions are described in separate sections in this manual.

Insight specific chart options


Orientation, Look ahead, 3D and **Change to Navionics/Change to Insight** (previously described in this section) are common for all chart types.

Chart imagery style

The charts can be displayed in two imagery styles, 2D basic mapping and shaded relief with terrain imaging.




Insight 2D mapping style



Insight Shaded relief

Insight view options



Insight Chart Details

Low	Basic level of information that cannot be removed, and includes information that is required in all geographic areas. It is not intended to be sufficient for safe navigation
Medium	Minimum information sufficient for navigation
Full	All available information for the chart in use

Insight chart categories

Insight charts include several categories and sub-categories that you can turn on/off individually depending on which information you want to see on your display.

Land Exaggeration and Water Exaggeration

Graphical settings available in 3D mode only. Exaggeration is a multiplier applied to the drawn height of hills on land, and troughs in water to make them look taller or deeper.


Navionics specific chart options

Orientation, Look ahead, 3D and **Change to Navionics/Change to Insight** (previously described in this section) are common for all chart types.

Community edits

Toggles on the chart layer including Navionics edits. These are user information or edits uploaded to Navionics Community by users, and made available in Navionics charts.

For more information refer to Navionics information included with your chart, or to Navionics website: www.navionics.com.



Navionics chart settings

Colored Seabed Areas

Used for displaying different depth areas in different shades of blue.

Presentation type

Provides marine charting information such as symbols, colors of the navigation chart and wording for either International or U.S. presentation types.

Annotation

Determines what area information, such as names of locations and notes of areas, is available to display.

Chart details

Provides you with different levels of geographical layer information.

Safety depth

The Navionics charts use different shades of blue to distinguish between shallow and deep water.

Safety depth, based on a selected limit, is drawn without blue shading.

→ **Note:** The built in Navionics database features data down to 20 m, after which it is all white.

Contours depth

Determines which contours you see on the chart down to the selected safety depth value.

Rock filter level

Hides rock identification on the chart beneath a given depth.

This helps you to declutter charts in areas where there are many rocks located at depths well below your vessel's draught.

Navionics view options





Chart shading

Shading adds terrain information to the chart.


Dynamic tide and current icons

Shows tides and currents with a gauge and an arrow instead of the diamond icons used for static tides and current information.

The tide and current data available in Navionics charts are related to a specific date and time. The Zeus² animates the arrows and/or gauges to show the tides and currents evolution over time.





Dynamic tide information



Dynamic current information

The following icons and symbology are used:

Icons	Description
	<p>Current speed. The arrow length depends on the rate, and the symbol is rotated according to flow direction. Flow rate is shown inside the arrow symbol. Red symbol used when current speed is increasing,- blue symbol when current speed is decreasing.</p>
	<p>Tide height. The gauge has 8 labels and is set according to absolute max/min value of the evaluated day. Red arrow used when tide is rising,- blue arrow when tide is falling.</p>

→ **Note:** All numeric values are shown in the relevant system units (unit of measurement) set by user.

Easy View


Magnifying feature that increases the size of chart items and text.

→ **Note:** There is no indication on the chart showing that this feature is active.

Photo overlay

Photo overlay enables you to view satellite photo images of an area as an overlay on the chart. The availability of such photos is limited to certain regions.


You can view photo overlays in either 2D or 3D modes.



No Photo overlay



Photo overlay, land only



Full Photo overlay

Photo transparency

The Photo transparency sets the opaqueness of the photo overlay. With minimum transparency settings the chart details will be almost hidden by the photo.

Navionics Fish N' Chip


Zeus² supports Navionics Fish N' Chip (U.S. only) chart feature.

For more information, see www.navionics.com.


Depth highlight range

Select a range of depths between which Navionics will fill with a different color.

This allows you to highlight a specific range of depths for fishing purposes. The range will only be as accurate as the underlying chart data, meaning that if the chart only contains 5 meter intervals for contour lines, the shading will round to the nearest available contour line.



No Depth highlight range




Depth highlight range: 6 m - 12 m


Shallow water highlight

Highlights areas of shallow water.

This allows you to highlight areas of water between 0 and the selected depth (up to 10 meters/30 feet).



No shallow water highlighted



Shallow water highlight: 0 m - 3 m


Jeppesen tides and currents

Zeus² can display Jeppesen tides and currents. With this information it is possible to predict the time, level, direction and strength of currents and tides. This is an important tool when considering planning and navigation of a trip.


In large zoom ranges the tides and currents are displayed as a square icon including the letter **T** (Tides) or **C** (Current). When you select one of the icons tidal or current information for that location are displayed.

Dynamic current data can be viewed by zooming inside a 1-nautical mile zoom range. At that range, the Current icon changes to an animated dynamic icon that shows the speed and direction of the current. Dynamic icons are colored in red (6 knots or higher), yellow (2 to 6 knots) or green (2 knots or less), depending of the current in that location.

If there is no current (0 knots) this will be shown as a white, square icon.




Static Current and Tide icons



Dynamic Current icons

Chart settings

Settings and display options made in the Chart settings page are common for all chart panels.



3D boat selection

Determines which icon to use on 3D charts.

Boat settings

The boat settings are used when calculating an automatic route. The boat's draught, width and height must be input to use the autorouting/easy routing features.

Range Rings


The range rings can be used to present the distance from your vessel to other chart objects. The range scale is set automatically by the system to suit the chart scale.

Vessels' extension lines

Sets the length of the extension lines for your vessel and for other vessels shown as AIS targets.

A: Heading


B: Course Over Ground (COG)




The length of the extension lines are either set as a fixed distance, or to indicate the distance the vessel will move in the selected time period. If no options are turned on for **This vessel** then no extension lines will be shown for your vessel.

Your vessel heading is based on information from the active heading sensor and COG from active GPS sensor.


For other vessels COG data is included in the message received from the AIS system.





Laylines

Configures the options for laylines on the chart and on the SailSteer panels. The image shows laylines from mark/waypoint with limits.



The following settings are available:

Boat	Displays laylines from boat, indicating the target course
Always show boat laylines	Displays boat laylines
Mark	Displays laylines from mark/waypoint, indicating the target course to sail to reach the mark/waypoint
Tidal flow correction	Calculates the tidal effect of the boat based on COG, and applies this information to the laylines.
Overlapped	Extends the laylines beyond the tack/gybe intersection
Length	Sets the length of the laylines
Target wind angle	Defines the target for the TWA (True Wind Angle). The target can be read from your polar table, it can be read from the live measurements, or it can be manually entered upwind and downwind sailing angles.
Limits	Sets the maximum tack/gybe time period to either side of the laylines. When turned on the limits are indicated with a dotted line on the chart and on the SailSteer panel

Synchronize 2D/3D chart

Links the position shown on one chart with the position shown on the other chart when a 2D and a 3D chart are shown side by side.

Pop-up information

Selects whether basic information for chart items will be displayed when you select the item.

Grid lines

Turns on/off viewing of longitude and latitude grid lines on the chart.

Course highway

Adds a graphic presentation of cross track error (XTE) limits to the route. For setting the XTE limit, see "XTE limit" on page 38.

Waypoints, Routes, Tracks

Turns on/off displaying of these items on chart panels.

5

Waypoints, routes and tracks

Waypoints

A waypoint is a user generated mark positioned on a chart or on a radar image. Each waypoint has an exact position with latitude and longitude coordinates.

A waypoint is used to mark a position you later may want to return to. Two or more waypoints can also be combined to create a route.

Saving waypoints

You can save a waypoint at a selected location by positioning the cursor on the panel, then selecting the new waypoint option in the menu.

If your unit has a **MARK** key, you can press this key to immediately save a waypoint. If the cursor is active the waypoint will be saved at the cursor position. If the cursor is not active the waypoint will be saved at your vessel's position.

Moving a waypoint


1. Select the waypoint you want to move
 - The waypoint icon will expand to indicate that it is active
2. Activate the menu and select the move option
3. Tap the chart to select a new position for the waypoint
4. Press the **Enter** key or the rotary knob to confirm the new position

The waypoint is now automatically saved at the new position.

Edit a waypoint

You can edit all information about a waypoint from the **Edit Waypoint** dialog. This dialog is activated by tapping the waypoint's pop-up, by pressing the rotary knob, or from the menu when the waypoint is activated.


The dialog can also be accessed from the Waypoints tool on the **Home** page.



Waypoint alarm settings

You can set an alarm radius for each individual waypoint you create. The alarm is set in the **Edit Waypoint** dialog.

- **Note:** The waypoint radius alarm must be toggled ON in the alarm panel to activate an alarm when your vessel comes within the defined radius.



Routes

A route consists of a series of routepoints entered in the order that you want to navigate them.

When you select a route on the chart panel it will turn green, and the route name will be displayed.

Zeus² 1.5 includes support for Navionics Autorouting and Jeppesen Easy Routing. This feature automatically suggest routepoints between the first and last routepoint of a route, or between selected routepoints in a complex route. You can use the feature when you create a new route, or you can use it to edit already saved routes.

Creating a new route on the chart panel

1. Activate the cursor on the chart panel
2. Select the new route option from the menu
3. Tap the chart panel to position the first waypoint
4. Continue positioning new routepoints on the chart panel until the route is completed
5. Save the route by selecting the save option in the menu.

Edit a route from the chart panel

1. Select the route to make it active
 2. Select the route edit option in the menu
 3. Tap the chart panel to position the new routepoint
 - If you set the new routepoint on a leg a new point will be added between existing routepoints
 - If you set the new routepoint outside the route the new routepoint will be added after the last point in the route
 4. Drag a routepoint to move it to a new position
 5. Save the route by selecting the save option in the menu
- **Note:** The menu will change depending on the selected edit option. All edits are confirmed or cancelled from the menu.

Autorouting and Easy Routing

The Autorouting and Easy Routing suggest new routepoint positions based on information in the map and on your boat's size. Before you can start using this feature the boat draught, width and height must be entered into the system. The boat settings dialog will automatically be displayed if the information is missing when you start the feature.

- **Note:** Zeus² units designed for sale in the U.S. region will not have Autorouting or Easy Routing capabilities. Autorouting or Easy Routing features are disabled on all non-U.S. units when they are used in U.S. territorial waters.
- **Note:** It is not possible to start the Autorouting or Easy Routing if one of the selected routepoints is located in an unsafe area. A warning dialog will be displayed, and you have to move the relevant routepoint(s) to a safe area to proceed.
- **Note:** If no compatible cartography is available the Autorouting or Easy Routing menu option will not be available. Compatible cartography includes Jeppesen CMAP MAX-N+, Navionics+ and Navionics Platinum. For a full selection of available charts please visit insightstore.navico.com, c-map.jeppesen.com or navionics.com.
1. Position at least two routepoints on a new route, or open an existing route for editing
 2. Select **Autorouting**, followed by:
 - **Entire Route** if you want the system to add new routepoints between the first and the last routepoint of the open route
 - **Selection** if you want to manually select the routepoints that define the limits for the autorouting, then select the relevant routepoints. Selected routepoints are colored red.

Only two routepoints can be selected, and the system will discard any routepoints between your selected start and end points

3. Select **Accept** to start the automatic routing
 - When the automatic routing is completed the route will appear in preview mode, and the legs are color coded to indicate safe or unsafe areas. Navionics uses red (unsafe) and green (safe), while C-MAP uses red (unsafe), yellow (dangerous) and green (safe).
4. Move any routepoints if required when the route is in preview mode
5. Select **Keep** to accept the routepoints positions
6. Eventually repeat step 2 (**Selection**) and step 3 if you want the system to automatically position routepoints for other parts of the route
7. Select **Save** to complete the automatic routing and save the route

Autorouting and Easy Routing examples

- **Entire route** option used when first and last route points are selected.



First and last routepoint



Result after automatic routing

- **Selection** option used for autorouting part of a route.




Two routepoints selected



Result after automatic routing


Creating routes using existing waypoints

You can create a new route by combining existing waypoints from the **Routes** dialog. The dialog is activated by using the **Routes** tool on the Home page.



Converting a track to a route


You can convert a track to a route from the **Edit Track** dialog. The dialog is activated by activating the track, then tapping the track's pop-up, pressing the rotary knob or selecting the info options from the menu. The **Edit Track** dialog can also be accessed by using the **Tracks** tool on the Home page.



The Edit Route dialog

You can add and remove routepoints from the **Edit Route** dialog. This dialog is activated by tapping an active route's pop-up, by pressing the rotary knob, or from the menu. The dialog can also be accessed by using the **Routes** tool on the Home page.





Tracks

A track is a graphical presentation of the historical path of the vessel, allowing you to retrace where you have travelled. A track can be converted to a route from the **Edit Tracks** dialog.

From the factory, the system is set to automatically track and draw the vessel's movement on the chart panel. The system will continue to record the track until the track length reaches the maximum track points, and will then automatically begin overwriting the oldest track points.

The automatic tracking function can be turned off from the **Tracks** dialog.

Creating a new track


You can start a new track from the **Tracks** dialog, activated by using the **Tracks** tool on the **Home** page.

Track settings

A track is made up of a series of track points connected by line segments whose length depends on the frequency of track recording.

You can select to position track points based on time settings, distance, or by letting the Zeus² system position a waypoint automatically when a course change is registered.


→ **Note:** The Tracks option must also be turned ON in the chart settings to be visible.



Waypoints, routes and tracks dialogs

The waypoints, routes and tracks dialogs give access to advanced edit functions and settings for these items.

The dialogs are accessed from the **Tools panel** on the **Home** page.



6

Navigating

The navigation function included in the Zeus² allows you to navigate towards the cursor position, towards a waypoint or along a predefined route.

If autopilot functionality is included in your system, the autopilot can be set to automatically navigate the vessel.

For information about positioning waypoints and creating routes, refer to "*Waypoints-Routes-Tracks*" on page 31.

Navigate to cursor position

You can start navigating towards cursor position on any chart, radar or echosounder panel. Position the cursor at the selected destination on the panel, and then select the go to cursor option in the menu.

Navigate a route

You can start navigating a route from the chart panel or from the **Route** dialog. When route navigation is started, the menu will expand showing options for canceling the navigation, for skipping a waypoint, and for restarting the route from current vessel position.


Starting a route from the chart panel

Activate a route on the panel, and then select the route navigation option from the menu. You can select a routepoint to start navigating from a selected position.

Start navigating a route from the Route dialog

You can start navigating from the **Route** dialog, activated by:

- Selecting the **Route** tool from the **Home** page
- Selecting the route details from the menu



Cancel navigation

When you are navigating a route the menu will include an option for cancelling the route.


Navigating with the autopilot

When you start navigation on a system with autopilot functionality, you will be prompted to set the autopilot to navigation mode.

If you choose not to engage the autopilot, the autopilot can later on still be set to navigation mode from the pilot menu.

For more information about autopilot functionality, refer to "*Autopilot*" on page 43.

Navigation settings



Navigation method

Different methods are available for calculating the distance and bearing between any two points on a chart.

The Great circle route is the shortest path between two points. However, if you are to travel along such a route, it would be difficult to steer manually as the heading would constantly be changing (except in the case of due north, south, or along the equator).

Rhumb lines are tracks of constant bearing. It is possible to travel between two locations using Rhumb line computation, but the distance would usually be greater than if Great circle is used.

Phantom Loran

Enables use of Phantom Loran positioning system.

Loran settings

Defines Loran chains (GRI) and preferred station for waypoint entry, cursor position and position panel.

The graphic example shows a cursor position window with Loran position information. For more information refer to your Loran system documentation.

```
N 23°02.024'  
W 76°35.080'  
26728.33 9960  
39030.51  
377.9 km, 143 °M
```

Arrival radius

Sets an invisible circle around the destination waypoint.

The vessel is considered arrived at the waypoint when it is within this radius.

XTE limit

This parameter defines the vessel's accepted offset distance from the leg. If the vessel goes beyond this limit, an alarm will be activated.

Arrival alarm

When the arrival alarm is enabled, an alarm will be activated when the vessel reaches the waypoint or when its within the specified arrival radius.

Magnetic variation

Magnetic variation is the difference between true bearings and magnetic bearings, caused by different locations of the Geographic and the Magnetic north poles. Any local anomalies such as iron deposits might also affect the magnetic bearings.

When set to Auto, the system automatically converts magnetic north to true north. Select manual mode if you need to enter your own local magnetic variation.

Datum

Most paper charts are made in the WGS84 format, which also is used by the Zeus² system.

If your paper charts are in a different format, you can change the datum settings accordingly to match your paper charts.

Coordinate system

Several coordinate systems can be used to control the format for lat./lon coordinates displayed on the chart panel.


7

The SailSteer panel

The SailSteer panel provides a composite view of key sailing data. All data is displayed relative to the yacht's bow, providing a clear and easy to understand image of important sailing data.

The SailSteer panel can be shown as a full screen panel, or in a multi-panel page.

The number of data fields included in the panel is dependant on available panel size.



Key	Description	Comment
1	User configurable data fields	
2	Vessel heading	
3	COG (Course Over Ground)	
4	Port and starboard laylines	Refer " <i>Chart settings</i> " on page 29
5	Magnetic or True reference	
6	TWA (True Wind Angle)	Green if on TWA upwind or downwind. Blue if off target by 10° or more , or on a free leg. The indicator will fade from blue to green the closer you get to the exact angle
7	Tide rate and relative direction	
8	Magnetic variation	
9	Bearing to current waypoint	
10	Rudder angle	
11	Current waypoint ID	

Selecting data fields for the SailSteer panel

Data sources connected to the system can be viewed on the SailSteer panel.

1. Tap the SailSteer panel to make it active
2. Tap the **MENU** button and select the edit option
 - Edit mode will be indicated in top of the panel
3. Tap the instrument field you want to change
 - The selected field will have a highlighted frame
4. Tap the **MENU** button again to select info
5. Repeat the steps to change other instrument fields
6. Save you settings by selecting the save option in the menu

Sail Time calculations

The Zeus² calculates the time and distance to a waypoint taking into consideration that the vessel is sailing via a layline course to the waypoint. Data showing time calculations will be indicated with an -S extention:

DTW-S	Sailing Distance to Waypoint
TTW-S	Sailing Time to Waypoint
ETA-S	Sailing Estimated Time of Arrival

8

Time and Wind plots

The Zeus² can present data history in different plots. The plots can be displayed in full page, or combined with other panels.


The Time plot panel

The Time plot panel consists of two predefined layouts. You switch between the layouts by selecting the left and right panel arrows. You can also select the layout from the menu.

You can select which data to present on a time plot panel, and you can define the time range for each plot.



Layout 1



Layout 2

Missing data

If the data is unavailable, the relevant plot will turn into a dashed line and flatten out at the point the data was lost. When the data becomes available again a dashed line will join up the two points showing an average trend line bridging the missing data.

Selecting data

Each data field can be changed to show the preferred data type and the time range.

1. Select the edit option from the menu
2. Activate the field you want to edit
3. Change the information type and eventually the range
4. Save your changes

The data available for the Time plots are by default the sources used by the system. If more than one data source is available for a data type you can select to show alternative data source in the Time plot. You change the data type by using the data source option in the menu.

Wind Plot panel

A Wind Plot is a special type of Time Plot specifically designed to help you understand recent changes in wind speed and direction. The Wind Plot panel includes wind direction and wind speed. The graphics are configured vertically with the newest data being displayed at the top of the screen.



9

Autopilot

If an AC12N, AC42N or SG05 autopilot computer is connected to the system, autopilot functionality will be available in the Zeus².

An Autopilot is designed to maintain an accurate course in various sea conditions with minimal helm movements.

Safe operation with the autopilot

⚠ Warning: An autopilot is a useful navigational aid, but DOES NOT replace a human navigator.

Activating the autopilot

You activate the autopilot from any panel by pressing the **STBY/AUTO** key, followed by selecting the selected mode in the autopilot pop-up.

Switching from automatic mode to manual steering

You can switch the autopilot to STBY mode from any automatic operation mode by a short press on the **STBY/AUTO** key.


- **Note:** If the Zeus² is connected to an EVC system via the SG05, you can take manual control of the steering regardless of the autopilot mode. Refer to *"Using the autopilot in an EVC system"* on page 52.



Autopilot indication on the pages



Key	Description
1	Autopilot indication in Status bar
2	Autopilot pop-up
3	Autopilot tile in Instrument bar



Autopilot mode indication in the Status bar

The Status bar will show autopilot information as long as an autopilot computer is connected to the network.

Icons will be included if the autopilot is passive or locked by another autopilot control unit.

Autopilot pop up


You control the autopilot from the autopilot pop-up.

The pop-up has a fixed position on the page, and it is available for all pages except when an Autopilot panel is active.

As long as the autopilot pop-up is active, you cannot operate the background panel or its menu.

You remove the pop-up from a page by selecting the **X** in the upper right corner, or by pressing the **X** key. You turn it on again by pressing and holding the **STBY/AUTO** key, or by selecting the autopilot tile in the instrument bar.

The following pop-ups are available:



Autopilot controller, showing active mode, heading, rudder and various steering information depending on active autopilot mode. Manual adjustments to the set heading can only be made when the port and starboard arrow indicators are illuminated red and green.



Mode selection, including access to turn pattern selection



Turn pattern selection



Autopilot tile in Instrument bar


You can elect to show the autopilot tile in the Instrument bar.

If the autopilot pop-up is turned off you can turn it on by selecting the tile in the Instrument bar.

The Autopilot panel

The autopilot panel is used to display navigation data. It can be shown as a full screen panel, or in a multi-panel page.

The number of data fields included in the autopilot panel is dependant on available panel size.



Data fields

The following abbreviations are used in the autopilot panel:

CTS	Course to steer
DTD	Distance to destination
WPT DIST	Distance to next waypoint
SOG	Speed over ground
COG	Course over ground
XTE	Cross track error (L: left or R: right)

Mode overview

The autopilot has several steering modes. The number of modes and features within the mode depend on boat type and available inputs, as shown in table.

Mode	Feature	Description
Standby		Standby mode used when manually steering at the helm. Compass and rudder angle will be shown on the display
NFU		Non-Follow Up steering where the rudder movement is controlled by using the Port and Starboard keys in the Pilot pop-up, or by another NFU unit
FU		Follow-up steering where the rudder angle is set by the rotary knob or by another FU unit
AUTO		Automatic steering where the set heading is maintained.
	Heading capture	Aborts the turn and uses the instantaneous compass reading as set heading
	Turn patterns	Moves the vessel automatically in pre-defined turn steering patterns
	Tacking	Only available if the boat type is set to Sail. Tacking with a fixed angle.
NoDrift		Automatic steering, keeping the vessel on a straight bearing line by compensating for drift
	Dodging	Returns to NoDrift mode after a heading change
NAV		Navigation steering. Steers the vessel to a specific waypoint or through a route

Mode	Feature	Description
WIND		Only available if the boat type is set to Sail. Automatic steering where the vessel heading is changed to maintain a set wind angle
	Tacking/Gybing	Only available if the boat type is set to Sail. Tacking/Gybing with apparent or true wing angle as reference.
WIND Nav		Automatic steering, using both wind and GPS data to steer the vessel to a specific waypoint or through a route

Standby mode

Standby (STBY) mode is used when you steer the boat at the helm.

- Switch the autopilot to STBY mode from any operation by a short press on the **STBY/AUTO** key.

Non-Follow Up (NFU, Power steering)

In **NFU** mode you use the port and starboard arrow buttons in the autopilot pop-up to control the rudder. The rudder will move as long as the button is pressed.

- Activate **NFU** mode by selecting the port or starboard arrow button in the pop-up when the autopilot is in **STBY** or **FU** mode.

You return to **STBY** mode by a short press on the **STBY/AUTO** key.

Follow-up steering (FU)

In **FU** mode you use the rotary knob to set the rudder angle. The rudder will move to the commanded angle and then stop.

- You select **FU** mode from the autopilot menu

→ **Note:** If the autopilot pop-up is closed or if an alarm dialog is activated on the Zeus² unit controlling the autopilot in **FU** mode, the autopilot will automatically change to **STBY** mode.

⚠ Warning: While in **FU** mode you cannot take manual control of the wheel. You return to **STBY** mode by a short press on the **STBY/AUTO** key.

AUTO mode (auto compass)

In AUTO mode the autopilot issues rudder commands required to steer the vessel automatically on a set heading.

- You select AUTO mode from the autopilot menu. When the mode is activated, the autopilot selects the current boat heading as the set heading.

Changing set heading in AUTO mode

You adjust the set heading by using the rotary knob or the Port/Starboard arrow buttons in the autopilot pop-up.

An immediate heading change will take place. The new heading will be maintained until a new heading is set.

Heading capture

When the vessel is turning in AUTO mode, an instant reset of the mode activates the heading capture function. This will automatically cancel the turn, and the vessel will continue on the heading read from the compass the very moment you re-activated the mode.

Tacking in AUTO mode

→ **Note:** The tack function is only available when the system is set up for SAIL boat type.



Tacking should only be performed into the wind and must be tried out in calm sea conditions with light wind to find out how it works on your boat. Due to a wide range of boat characteristics (from cruising to racing boats) the performance of the tack function may vary from boat to boat.

Tacking in **AUTO** mode is different from tacking in **WIND** mode. In AUTO mode the tack angle is fixed and as defined by the user. For more details, see "*Tacking - WIND mode*" on page 49.

You initiate the tack function from **AUTO** mode.

When tacking direction is selected the autopilot changes the current set course according to the set fixed tacking angle.

You can interrupt the tack operation as long as the tack dialog is open by selecting the opposite tacking direction. When interrupted the boat will return to the previous set heading.

NoDrift mode

NoDrift mode combines the autopilot and the positioning information from the GPS.

In NoDrift mode the vessel is steered along a calculated track line in a direction set by the user. If the vessel's heading is drifting away from the original heading due to current and/or wind, the vessel will follow the line with a crab angle.

1. Turn the vessel to the desired heading
2. Activate the NoDrift mode. The autopilot will draw an invisible bearing line based on current heading from the boat's position

Unlike in AUTO (compass) mode the autopilot will now use the position information to calculate the cross track error, and automatically keep your track straight.

You use the port/starboard arrow panel buttons in the autopilot pop-up or the rotary knob to reset the bearing line while in NoDrift mode.

Dodging

If you need to avoid an obstacle when using NoDrift mode, you can set the autopilot to STBY and power steer or use the helm until the obstacle is passed.

If you return to NoDrift mode within 60 seconds you can select to continue on previous set bearing line.

If you don't respond the dialog will disappear and the autopilot will go to NoDrift mode with current heading as set bearing line.

NAV mode

Warning: NAV mode should only be used in open waters.

You can use the autopilot to automatically steer the boat to a specific waypoint location, or along a pre-defined route. The position information from the GPS will be used to change the course to steer to keep the boat on the track line and to the destination waypoint.

→ **Note:** To obtain satisfactory navigation steering, the Zeus² must have valid position input. Autosteering must be tested and determined satisfactory prior to entering the NAV mode.

Start automatic navigating

When you start navigating a route or to a waypoint from the chart panel, you will be prompted to set the autopilot to **NAV** mode. If you reject this request, you can start **NAV** mode from the autopilot mode menu.


When **NAV** mode is initiated, the autopilot will automatically keep the vessel on the leg.

When the vessel reaches the arrival circle for a routepoint, the autopilot will give an audible warning and display a dialog with the new course information. If the required course change to the next waypoint is less than the Navigation change limit, the autopilot will automatically change the course. If the required course change to next waypoint in a route is more than the set limit, you are prompted to verify that the upcoming course change is acceptable.

→ **Note:** For information about navigation settings, refer to "*Navigation settings*" on page 38.


Waypoint arrival circle

The Arrival radius defines the point at which a turn is initiated when you are navigating a route.



The arrival circle should be adjusted according to boat speed. The higher the speed, the wider the circle. The intention is to make the autopilot start the heading change in due time to make a smooth turn onto the next leg.

The figure below may be used to select the appropriate waypoint circle when creating the route.



Example: With the speed of 20 knots you should use a waypoint circle with radius 0.09 nm.

→ **Note:** The distance between any waypoints in a route must not be smaller than the radius of the waypoint arrival circle when using automatic waypoint shift.

WIND mode

→ **Note:** The **WIND** mode is only available if the system has been set up for sailboat in the Autopilot Installation menu.

Before the **WIND** mode is started it must be verified that valid input from wind transducer is available.

Initiate wind steering as follows;

1. Switch the Autopilot to **AUTO** mode
2. Adjust the boat heading until wind angle is according to the angle you want to maintain
3. Select the mode indication in the autopilot controller to activate the autopilot menu, and select **WIND** mode

The set course to steer (CTS) and set wind angle are entered from the compass heading and the wind transducer at the moment the **WIND** mode is selected. From that point the autopilot will change the course to maintain the wind angle as the wind direction may change.

Tacking in WIND mode

→ **Note:** The tack function is only available when the system is set up for SAIL boat type.



Tacking should only be performed into the wind and must be tried out in calm sea conditions with light wind to find out how it works on your boat. Due to a wide range of boat characteristics (from cruising to racing boats) the performance of the tack function may vary from boat to boat.

Tacking in **WIND** mode as compared to **AUTO** mode is performed when sailing with apparent or true wind as the reference. The true wind angle should be less than 90 degrees. The rate of turn during the tack will be given by the Tack time defined in the sailing parameter setup. The tack time is also controlled by the speed of the boat to prevent loss of speed during a tack.

You can initiate the tack function from **WIND** mode.

When you initiate the tacking, the autopilot will immediately mirror the set wind angle to the opposite side of the bow.

You can interrupt the tack operation as long as the tack dialog is open by selecting the opposite tacking direction. When interrupted the boat will return to the previous set heading.

Gybing

Gybing is possible when the true wind angle is larger than 120°.

The time to make a gybe is determined by the speed of the boat to make it as quick as possible within control.

Tack and gybe prevent

You should use the autopilot with care when beating and running.

If the sails are unbalanced when beating, yaw forces from the sails can drive the boat into the wind. If the boat is driven beyond the set minimum wind angle, the thrust from the sails will suddenly disappear and reduces the boat speed. The boat will then be more difficult to steer as the rudder will become less effective.

The tack prevent function in WIND mode has been implemented to avoid such situations. It will react immediately when the apparent wind angle becomes 5° less than the set minimum wind angle, and more rudder will be commanded.

When running, it is difficult to steer the boat with waves coming sideways or from behind. The waves may yaw the boat into an unwanted gybe; this can be hazardous for both the crew and the mast.

The gybe prevent function will be activated when the actual apparent wind angle becomes greater than 175° or gets opposite to the set wind angle. More rudder will be commanded to prevent an unwanted gybe.

The tack and gybe prevent functions are not a guarantee against getting into a hazardous situation. If the effect of the rudder and/or drive unit is not adequate, a dangerous situation may occur. Pay particular attention in such situations.

WIND Nav mode

In WIND Nav mode the autopilot steers the boat given both wind and position data.

In this mode the autopilot calculates the initial course change needed to navigate towards the active waypoint, but the pilot will also utilize the current wind direction in the calculation.



Turn pattern steering

The autopilot includes a number of automatic turn steering features for power boats when the pilot is in AUTO mode.

- **Note:** The turn steering option will not be available if the boat type is set to sailboat - instead the tack/gybe feature is implemented.

Initiating a turn

You start the turn by selecting the relevant turn icon, followed by selecting the port or starboard options in the turn dialog to select the turn direction.

Stopping the turn

You can stop the turn from within the turn dialog.

You can also at any time during a turn pressing the **STBD/AUTO** key to return to standby mode and manual steering.

Turn variables

All turn steering options, except the C-turn, have settings that you may adjust before you start a turn and at any time when the boat is in a turn.

U-turn

U-Turn changes the current set heading to be 180° in the opposite direction.

The turn rate is identical to Rate limit settings. This cannot be changed during the turn.

- **Note:** Refer to the separate Zeus² Installation manual for information about Rate limit settings.

C-turn

C-turn makes the boat turn in a circle.

You can adjust the Rate of turn from the turn dialog before the turn is initiated and during the turn. Increasing the turn rate makes the boat turn a smaller circle.

Spiral turn

Spiral-turn makes the boat turn in a spiral with a decreasing or increasing radius. This feature may be used for circling fish or when searching an object.

You set the initial radius before the turn is initiated, and the change per turn during the turn. If the change per turn is set to zero, the boat will turn in a circle. Negative values indicate decreasing radius while positive values indicate increasing radius.

Zigzag turns

For navigating in a zigzag pattern, you set the initial heading change before the turn is started.

During the turn you can alter the main heading, the heading change and the leg distance.

Square turn

Square-turn makes the boat automatically turn 90° after having travelled a defined leg distance.

You can at any time during the turn change the main heading and the distance of the leg until the boat makes a new 90° turn.

Lazy S-turn

In the lazy-s turn the boat will yaw around the main heading.


You set the selected heading change before the turn is started.

During the turn you can alter the main heading, the heading change and the turn radius from within the turn dialog.

Depth contour tracking, DCT™

If the system has input from an echosounder, the autopilot can be set to follow a depth contour.

⚠ Warning: Do not use this feature unless the seabed is suitable. Do not use it in rocky waters where the depth is varying significantly over a small area.



Use the following process to initiate DCT steering;

1. Ensure that you have depth reading on the Zeus² or on a separate depth instrument
2. Steer the boat to the depth you want to track, and in the direction of the depth contour
3. Activate **AUTO** mode, select depth contour steering and monitor the depth reading
4. Select the port or starboard option in the turn dialog to initiate the depth contour steering to follow the bottom sloping to starboard or to port

The following parameters are available for depth contour tracking:

Depth gain

This parameter determines the ratio between commanded rudder and the deviation from the selected depth contour. The higher depth gain value the more rudder is applied.

If the value is too small it will take a long time to compensate for drifting off the set depth contour, and the autopilot will fail to keep the boat on the selected depth.

If the value is set too high the overshoot will increase and the steering will be unstable.

Contour Cross Angle CCA

The CCA is an angle that is added to or subtracted from the set course.

With this parameter you can make the boat yaw around the reference depth with lazy-s movements.

The larger the CCA the bigger yawing will be allowed. If you the CCA set to zero there is no S-ing.


Using the Zeus² in an AP24/AP28 system

Command transfer

If your Zeus² unit is connected to an autopilot system including an AP24 or AP28 control unit, only one control unit can be active at the same time. An inactive Zeus² unit is indicated with a square with a cross symbol in autopilot controller pop-up.

You can take command from an inactive Zeus² unit by pressing the **STBY/AUTO** key to bring up the mode selection menu, and then confirming active mode.





Locking remote stations

The AP24/AP28 includes a Remote Lock function that will disable autopilot control from other units. A locked Zeus² unit is indicated with a key symbol in autopilot controller pop-up. When the remote lock function is enabled on an AP24/AP28 control unit, only the active control unit stays in command. No transfer of command to Zeus² or other autopilot control units on the system can take place,

You can only unlock the remote stations from the AP24/AP28 unit in command.



Using the autopilot in an EVC system

When the Zeus² is connected to an EVC system via the SG05, you can take manual control of the steering regardless of the autopilot mode.

The mode indicator on the pilot pop-up will be replaced by a dash to indicate EVC override.

The system will return to Zeus² control in standby mode if no rudder command is given from the EVC system within a predefined period.

Autopilot settings





Chart compass



You can elect to show a compass symbol around your boat on the chart panel. The compass symbol will be off when the cursor is active on the panel.

Locking autopilot use for other units

If two Zeus² units are included in the system, the non-active Zeus² unit can be locked to prevent unauthorized operation of the autopilot.

When the unit is locked this is indicated with a lock symbol and with text in the pop up.

When the lock function is in use, no automatic modes can be selected from the Zeus² unit.

→ **Note:** The lock function is not available on the Zeus² unit which has autopilot control!

If the Zeus² unit is part of an AP24/AP28 system, the unit can be locked from the AP24/ AP28 control unit.

Sea state filter

The Seastate filter is used to reduce rudder activity and autopilot sensitivity in rough weather.

OFF	Seastate filter is disabled. This is default
AUTO	Reduces rudder activity and autopilot sensitivity in rough weather by an adaptive process. The AUTO setting is recommended if you want to use the seastate filter
MANUAL	Linked to the steering response control settings described previously. It may be used to manually find the optimum combination of course keeping and low rudder activity in rough but steady sea conditions

Sailing parameters

→ **Note:** Sailing parameter settings are only available if the boat type is set to Sail.

Tack time

When performing a tack in WIND mode, the rate of turn (tack time) can be adjusted. This will give single-handed sailors time to handle the boat and the sails during a tack.

A turn performed without shifting wind side, will also be made at a controlled turn rate.

Tack angle

This value is used to preset the course change used when tacking in AUTO mode. By pressing the port and starboard indicators in the autopilot pop-up the course will change as much as this value.

Wind function

With wind function set to AUTO, the autopilot will automatically select between apparent and true wind steering. AUTO is default and recommended for cruising.

When the boat is running, it will also be surfing on the waves. This may lead to significant changes in boat speed, and thereby also changes in apparent wind angle. True wind steering is therefore used when running, while steering to apparent wind is used when beating or reaching.

Apparent wind steering is preferred when you want to achieve maximum boat speed. The autopilot tries to maintain a constant apparent wind angle to get maximum thrust from a given trim of the sails.

When sailing in closed waters, the apparent wind angle may change temporarily due to wind gusts. It may then be preferred to sail to the true wind.

VMG optimizing

You can optimize the VMG to wind. When selected, the function will be active for 5–10 minutes after a new wind angle has been set and only when beating.

Layline steering

Layline steering is useful when navigating. Cross Track Error (XTE) from the navigator will keep the boat on the track line. If the XTE from the navigator exceeds 0.15 NM, the autopilot will calculate the layline and track towards the waypoint.

Response

By default the system switches between HI/LO parameter set based on speed (motor boats) or speed and wind (sail boats). You can however manually select which parameter set that shall be used.

HI or LO must be selected if no speed input is available.

You can manually fine tune each of the two (HI/LO) parameter sets. Level 4 is default with parameter values as set by the autotune function. If no autotune is made (not recommended) the level 4 values are the factory default values.

A low response level reduces the rudder activity and provides a more "loose" steering.

A high response level increases the rudder activity and provides a more "tight" steering. A too high response level will make the boat start S-ing.

Automatic steering

This option displays an overview of all autopilot steering parameters, and you can adjust parameters if required.

For more details, refer to the separate Zeus² Installation manual.

Installation

Used for autopilot installation and commissioning. See the separate Zeus² Installation manual.

10


Radar

The radar panel can be set up as a full screen view or combined with other panels.

The radar image can also be displayed as an overlay to existing 2D and 3D chart views. For more information see *"Chart overlay"* on page 24.

→ **Note:** Radar overlay requires data from heading sensor.

The radar panel



Key	Description	Comment
1	Range	
2	Orientation	
3	Motion	
4	Compass	*
5	Heading line	*
6	Rotary controls	
7	Range rings	*
8	Range markers	*
9	Data bar	

* Optional radar symbology.

Radar symbology can be turned ON/OFF collectively from the Radar menu, or individually as described in *"Radar settings panel"* on page 62.

Radar overlay

You can overlay the Radar image on the Chart. This can help you to easily interpret the radar image by correlating the radar targets with charted objects.

When the radar overlay is selected, basic radar operational functions are available from the Chart panel's menu.

Radar operational modes

The radar's operational modes are controlled from the Zeus² unit. The following modes are available:

Off

The power to the radar scanner is turned off

Standby

The power to the radar scanner is on, but the radar is not transmitting.

Transmit

The scanner is on and transmitting. Detected targets will be drawn on the radar PPI (Plan Position Indicator).

Radar Range

You adjust radar range by turning the rotary knob or by selecting the zoom icons on the radar panel.

Using the cursor on a radar panel

By default, the cursor is not shown on a radar panel.

When you position the cursor on the radar panel the cursor window is activated.

The cursor can be used to measure a distance to a target, and to select targets as described later in this section.


To remove the cursor and cursor elements from the panel, select **Clear cursor** or press the **X** key.

GoTo cursor

You start navigating to a selected position on the image by positioning the cursor on the panel, then using the go to cursor option in the menu.

The Cursor assist function

When using a touch screen, the cursor assist function allows for fine tuning and precision placement of the cursor without covering details with your finger.



Press and hold your finger on the screen to switch the cursor symbol to a selection circle, appearing above your finger.


Without removing your finger from the screen, drag the selection circle over the desired item to display item information.

When you remove your finger from the screen the cursor reverts to normal cursor operation.

Saving waypoints

You can save a waypoint at a selected location by positioning the cursor on the panel, then selecting the new waypoint option in the menu.

If your unit has a **MARK** key, you can press this key to immediately save a waypoint. If the cursor is active the waypoint will be saved at the cursor position. If the cursor is not active the waypoint will be saved at your vessel's position.



Adjusting the radar image

You may be able to improve the radar image by adjusting the radar sensitivity, and by filtering out the random echoes from sea and weather conditions.

The radar control images are located in the upper right corner of the radar panel. You select between the control images by selecting the control image or by pressing the rotary knob. Active control will expand and display its name in full. You can then adjust the value by turning the rotary knob or by using the slide bar.

You can also adjust the image settings from the radar menu.

Gain

The gain controls the sensitivity of the radar receiver.

A higher gain makes the radar more sensitive to radar returns, allowing it to display weaker targets. If the gain is set too high, the image might be cluttered with background noise.

Gain has a manual and an automatic mode. You toggle between automatic and manual mode in the slide bar, or by pressing and holding the rotary knob.

Sea clutter

Sea clutter is used to filter the effect of random echo returns from waves or rough water near the vessel.

When you increase Sea clutter filtering the on-screen clutter caused by the echoes of waves will be reduced.

The system includes predefined Sea clutter settings for harbor and offshore conditions, in addition to the manual mode where you can adjust the settings. You select Sea clutter modes from the menu, or by a long press on the rotary knob. You can only adjust the Sea clutter value in manual mode.

Rain Clutter

The Rain clutter is used to reduce the effect of rain, snow or other weather conditions on the radar image.

The value should not be increased too much as this may filter out real targets.


Rejecting radar interference

Interference could be caused by radar signals from other radar units operating in the same frequency band.

A high setting will reduce the interference from other radars.

In order not to miss weak targets, the interference rejection should be set low when no interference exists.

The radar interference rejection option is available from the menu.



Advanced radar options

Radar threshold

The threshold sets required signal strength for the lowest radar signals. Radar returns below this limit will be filtered and not displayed.

Default value: 30%.

Target boost

The target boost option is used for increasing the size of radar targets.

Target expansion

Target expansion will override and increase the default radar pulse length, providing larger target returns.

Fast scan

(Broadband Radar™ only).


Increases the speed of the radar scanner when the range is set to 2 nm or less. This option gives faster updates on target movements within this range.

STC curve

(Broadband Radar™ only).

The STC (Sensitivity Time Control) controls the sensitivity of the radar signal close to your vessel. It compensates for distance to the radar object, making returns from equal sized objects appear with the same size on the radar image.

Radar view options



Radar symbology

Radar symbology defined in the the Radar Settings panel can be turned on/off collectively. See the radar panel illustration showing optional radar items.

Target trails

You can set how long the trails generated from each target on your radar panel remain. You can also turn OFF target trails.

→ **Note:** True motion is recommended when using Target trails

Clearing target trails from the panel

When target trails are displayed on the panel, the radar menu will be expanded to include an option where you can clear target trails from your radar panel temporarily. The target trails will start to appear again unless you switch them off as described above.

The radar palette

Different colors (palettes) can be used to represent detail on your radar panel.

Radar orientation

Radar orientation is indicated on the upper left corner of the radar panel as either HU (Heading UP), NU (North Up) or CU (Course up).

Heading up

Rotates the radar image to display the current heading directly up on the radar image.

North up

Rotates the radar image with the north direction upwards.

Course up

Rotates the radar image to display the current navigation course directly up.


This option works only when the Zeus² is navigating an active route. If you are not navigating an active route the heading up orientation will be used until the navigation function is started.

Positioning the radar center

You can move the radar PPI (Plan Position Indicator) center to different positions within the radar panel, and select how your vessel symbol moves on the radar image.

Radar motion is indicated on the upper left corner of the radar panel as either TM (True motion) or RM (Relative motion).

The radar position can only be changed when the radar is transmitting.



Center

Look ahead

Custom offset

Center

Default setting. The radar PPI center is centered on the radar panel.

Look Ahead

Moves the radar PPI center to the bottom of the panel to maximize the view ahead.

Offset

Allows you to move the PPI center to any location on the radar panel.


1. Select the offset option from the menu
2. Move the cursor to where you want to position the radar center
3. Confirm the setting by selecting the save offset option in the menu.

True motion

In True motion, your vessel and moving targets move across the Radar screen as you travel. All stationary objects remain in a fixed position. When the vessel's symbol reaches the edge of the screen, the radar image will be redrawn with the vessel symbol repositioned in the center of the screen.

When True motion is selected, the menu will expand to include a reset true motion option. This allows for manually resetting the radar image and vessel symbol to the center of the screen.

EBL/VRM markers



The electronic bearing line (EBL) and variable range marker (VRM) allows quick measurements of range and bearing to vessels and landmasses within radar range. Two different EBL/VRMs can be placed on the radar image.

The EBL/VRM is by default positioned from the center of the vessel. It is however possible to offset the reference point to any selected position on the radar image.

When positioned, you can turn the EBL/VRM on/off by selecting the relevant markers on the data bar, or by deselecting the marker from the menu.

Defining an EBL/VRM marker

1. Ensure that the cursor is not active
2. Activate the menu, select **EBL/VRM**, then select **EBL/VRM 1** or **EBL/VRM 2**
 - The EBL/VRM is now positioned on the radar image
3. Select the adjustment option from the menu if you need to reposition the marker, then adjust the marker by dragging it into position on the radar image
4. Select the save option in the menu to save your settings

Placing EBL/VRM markers by using the cursor


1. Position the cursor on the radar image
2. Activate the menu
3. Select one of the EBL/VRM markers
 - The EBL line and the VRM circle will be positioned according to the cursor position

Offsetting an EBL/VRM marker

1. Ensure that the cursor is not active
2. Activate the menu, select **EBL/VRM**, then select the marker you wish to offset
3. Select the set offset option
4. Position the cursor on the radar panel to set the offset position
5. Select the save option in the menu to save your settings.

You can reset the EBL/VRM center to vessel position from the menu.

Setting a guard zone around your vessel



A guard zone is an area (either circular or a sector) that you can define on the radar image. When activated, an alarm will alert you when a radar target enters or exits the zone.

Defining a guard zone

1. Ensure that the cursor is not active
2. Activate the menu, select **Guard zones**, then select one of the guard zones
3. Select the shape for the zone
4. Select **Adjust** to set the range and depth for the guard zone. The values can be set from the menu or by dragging on the radar panel
5. Select the save option in the menu to save your settings.

When positioned, you can turn the guard zones on/off by selecting the relevant section on the data bar.

Alarm settings

An alarm will be activated when a radar target breaches the guard zone limits. You can select if the alarm will be activated when the target enters or exits the zone.

Sensitivity

The guard zone sensitivity can be adjusted to eliminate alarms for small targets.

MARPA targets

If the Zeus² system includes a heading sensor, the MARPA function (Mini Automatic Radar Plotting Aid) can be used to track up to ten radar targets.







You can define alarms to notify you if a target gets too close. Refer "*Radar settings panel*" on page 62.

MARPA tracking is an important tool for collision avoidance.

→ **Note:** MARPA requires heading data for both the radar and the Zeus².

MARPA target symbols

The Zeus² system use the target symbols shown below.

Symbol	Description
	Acquiring MARPA target. Typically it takes up to 10 full rotations of the scanner
	Tracking MARPA target, not moving or at anchor.
	Tracking and safe MARPA target with extension lines.
	Dangerous MARPA target. A target is defined as dangerous when it enters the guard zone defined on the radar panel.
	When no signals have been received within a time limit a target will be defined as lost. The target symbol represents the last valid position of the target before the reception of data was lost.
	Selected MARPA target, activated by positioning the cursor on the target icon. The target will return to default target symbol when the cursor is removed.

Tracking MARPA targets

1. Position the cursor on the target on the radar image
2. Select **Acquire targets** from the menu
3. Repeat the process if you want to track more targets

Once your targets are identified, it may take up to 10 radar sweeps to acquire and then track the target.

Cancelling MARPA target tracking

When targets are being tracked, the radar menu will expand to include options for cancelling individual targets or to stop the tracking function.

Cancel tracking individual targets by selecting the target icon before activating the menu.

Viewing MARPA target information

If the pop-up is activated, you can select a MARPA target to display basic target information. Information for the 3 MARPA targets closest to the vessel is also displayed in the data bar.

When a target is selected, detailed information for the target can be displayed from the menu.

You can display information about all MARPA targets by using the **Vessels** option on the Home page.

MARPA alarm settings

You can define the following MARPA alarms.

Alarm ID	Description
MARPA target lost	Controls whether an alarm shall be activated when a MARPA target is lost
MARPA unavailable	Controls whether an alarm shall be activated if you do not have the required inputs for MARPA to work (valid GPS position and heading sensor connected to the radar server)


Recording radar data

You can record radar data and save the file internally in the Zeus² unit, or save it onto an SD card inserted into the unit's card reader.

A recorded radar file can be used for documenting an event or an operational error. A logged radar file can also be used by the simulator.

If more than one radar is available you can select which source you want to record.

Radar settings



Radar symbology

You can select which optional radar items that should be turned on/off collectively from the menu. Refer to the Radar panel illustration.

Bearings

Used for selecting whether the radar bearing should be measured in relation to True Magnetic North (°T/°M) or to your relative heading (°R).

Data bar

Turns on/off the radar data bar. Refer to the radar panel illustration.

The data bar can show up to 3 targets, arranged with the most dangerous targets on top. You can select to show MARPA targets on top and before any AIS targets, even if the AIS targets are closer to your vessel.

MARPA settings

You can define the length of the MARPA trail making it easier to follow target movement.

A circle can be added around your vessel to present the danger zone. The radius of the the ring is the same as the closest point of approach as set in Dangerous Vessels dialog. See

"Defining dangerous vessels" on page 83. An alarm will trigger if a vessel is tracking into your safe zone.

Installation

The Installation option is used for radar installation, described in the separate Zeus² Installation manual.


11

Echosounder

The echosounder function provides a view of the water and bottom beneath your vessel, allowing you to detect fish and examine the structure of the sea floor.

The Zeus² units do not include built in echosounder or StructureScan. An external module such as the SonarHub, BSM-3 or other compatible modules must be available on the network to be able to use echosounder functionality on the Zeus².

The Echosounder image



Key	Description	Comment
1	Depth	
2	Temperature	
3	Frequency / Zoom	
4	Gain / Color adjustment icons	
5	Fish arches	
6	Upper and Lower range	
7	A-Scope	*
8	Temperature graph	*
9	Zoom bars	*
10	Range scale	
11	Depth line	*
12	Bottom	

* Optional echosounder image items.

→ **Note:** You turn the optional echosounder images on/off individually. See "*Echosounder settings panel*" on page 69.

Zooming an Echosounder image

You zoom an Echosounder image by:

- turning the rotary knob
 - using the panel zoom icons
 - by pinching or spreading on the screen
- Zoom level is shown on the upper left side of the panel.

When zooming in, the sea floor will be kept near the bottom of the screen, irrespective of whether it is in auto-range or manual range.

If the range is set considerably less than the actual depth, the unit will not be able to find the bottom when zooming.

If the cursor is active, the unit will zoom in where the cursor is pointed.

Zoom bar

The zoom bar will be displayed when you zoom the echosounder image.

Drag the zoom bar vertically to view different parts of the water column.

Using the cursor on the echosounder panel

The cursor can be used to measure a distance to a target, to mark a position, and to select targets.

The cursor is by default not shown on the echosounder image.

When you tap the screen the depth at the cursor position will be shown, the information window and the history bar will be activated.


To remove the cursor and cursor elements from the panel, select **Clear cursor** or press the **X** key.

GoTo cursor

You start navigating to a selected position on the image by positioning the cursor on the panel, then using the go to cursor option in the menu.

The Cursor assist function

When using a touch screen, the cursor assist function allows for fine tuning and precision placement of the cursor without covering details with your finger.



Press and hold your finger on the screen to switch the cursor symbol to a selection circle, appearing above your finger.

Without removing your finger from the screen, drag the selection circle over the desired item to display item information.

When you remove your finger from the screen the cursor reverts to normal cursor operation.

Measuring distance

The cursor can be used to measure the distance between the position of two observations on the image.

It is easier to use the measuring function when the image is paused.

1. Position the cursor on the point from where you want to measure the distance
2. Start the measuring function from the menu
3. Position the cursor on the second measuring point
 - A line will be drawn between the measuring points, and the distance will be listed in the Information window
4. Continue selecting new measuring points if required

You can use the menu to re-position the start point and the end point as long as the measuring function is active.

When you select **Finish measuring** or press the **X** key, the image will resume to normal scrolling.

Saving waypoints

You can save a waypoint at a selected location by positioning the cursor on the panel, then selecting the new waypoint option in the menu.

If your unit has a **MARK** key, you can press this key to immediately save a waypoint. If the cursor is active the waypoint will be saved at the cursor position. If the cursor is not active the waypoint will be saved at your vessel's position.

Viewing sounder history

Whenever the cursor is shown on a sounder panel, the scroll bar is shown at the bottom of the panel. The scroll bar shows the image you are currently viewing in relation to the total echosounder image history stored.

If the scroll bar is on the far right side, it indicates that you are viewing the latest soundings. If you position the cursor to the left side of the screen, the history bar will start scrolling towards left, and the automatic scrolling as new soundings are received will be turned off.

You can view echosounder history by panning the sonar image.

To resume normal scrolling, select **Clear cursor** or press the **X** key.

Setting up the Echosounder image

The range

The range setting determines the water depth that is visible on the screen.

Auto range

If you select Auto, the system will automatically display the whole range from the water surface to the bottom.

Preset range levels

You can select between several preset range levels.

Custom range

This option allows you to manually set both upper and lower range limits.

The echosounder panel can be setup as a single view, or with split view where the left and the right side presents different images.

Echo frequency

The Zeus² unit supports several transducer frequencies. Available frequencies depend on sounder module and which transducer model is connected.

You can view two frequencies at the same time by setting up a dual echosounder.

Color and gain settings

Gain and Color control images are located in the left side of the echosounder panel. You select between the control images by selecting the image or by pressing the rotary knob. Active control will expand and display its name in full. You can then adjust the value by turning the rotary knob or by using the slide bar.

You can also adjust the image settings from the echosounder menu.

Gain

The gain controls the sensitivity of the echosounder.

The more you increase the gain, the more details will be shown on the image. However, a higher gain setting may introduce more background clutter on the image. Conversely, if the gain is set too low weak echoes may not be displayed.

Auto gain

The Auto gain option will keep the sensitivity at a level that works well under most conditions.

With the gain in auto mode, you can set a positive or negative offset that gets applied to the auto gain. This is indicated as A-40 - A40.

Color

Strong and weak echo signals have different colors to indicate the different signal strengths. The colors used depend on which palette you select.

The more you increase the Color setting, the more echoes will be displayed in the color at the strong return end of the scale.

Pausing the echosounder

You can pause the sounder, allowing you to examine the sounder echoes.

This function is useful when you need to position a waypoint exactly on the echosounder panel, and if you are using the cursor to measure a distance between 2 elements on the image.

Advanced Echosounder options

Noise rejection

Signal interference from bilge pumps, engine vibration and air bubbles can clutter the image.

The noise rejection option filters the signal interference and reduces the on-screen clutter.

TVG

The TVG (Time Variable Gain) option compensate for distance to the object, making echoes from equal sized objects appear with the same size on the echosounder image.

Scroll speed

You can select the scrolling speed of the echosounder image on the screen. A high scroll speed will update the image fast, while a low scroll speed will present a longer history.

The ping speed

The Ping Speed controls the rate the transducer transmits into the water. A high ping speed will make the image move fast on the screen, while a low ping speed will present a longer history on the screen. The reverberation potentially caused by too high ping speed can cause interference on the screen.

Recording echosounder data

You can record echosounder and StructureScan data and save the file internally in the Zeus² unit, or save it onto an SD card inserted into the unit's card reader.

The function is activated from the **Advanced** menu option.

The following options are available:

Bytes per sounding

Select how many bytes per seconds that are to be used when saving the log file. More bytes yield better resolution, but will cause the record file to increase in size compared to using lower byte settings.

Log all channels

Logs all available sonar data simultaneously.

When logging all channels, logs are saved in .sl2 format instead of .slg format.

Log in XTF format

Optional logging format for SideScan data. This will only be shown when StructureScan data is available.

This format does not log all channels into onen file. The format is used for third part application support on PC (like SonarWiz) that needs access to the StructureScan data.

Create StructureMap when completed

If StructureScan is available on the network, you can convert the loggings to StructureMap format (.smf) after recording. The file can also be converted to StructureMap format from the Files option.

Viewing the recorded sounder data

Both internally and externally stored sounder records may be reviewed when selected.

The log file is displayed as a paused image, and you control the scrolling and display from the replay menu.

You can use the cursor on the replay image, and pan the image by tapping and dragging on the screen as on a normal echo image.

If more than one channel was recorded in the selected echo file, you can select which channel to display.

You exit the replay mode by pressing the **X** key or by selecting the **X** symbol in the upper right corner of the replay image.

Echosounder view options

Split screen options

Zoom

The Zoom mode presents a magnified view of the sounder image on the left side of the panel.

By default the zoom level is set to 2x. You can select up to 8x zoom from the drop-down menu.

The range zoom bars on the right side of the display shows the range that is magnified. If you increase the zooming factor the range will be reduced. You will see this as reduced distance between the zoom bars.

Bottom lock

The bottom lock mode is useful when you want to view echoes close to the bottom.

In this mode the left side of the panel shows an image where the bottom is flattened. The range scale is changed to measure from the seabed (0) and upwards. The bottom and the zero line will always be shown on the left image, independent on range scale.

The scaling factor for the image on the left side of the panel is adjusted as described for the Zoom option.

Palettes

You can select between several display palettes optimized for a variety of fishing conditions.

Temperature graph

The temperature graph is used to illustrate changes in water temperature.

When toggled on a colored line and temperature digits are shown on the echosounder panel.

Depth line

A depth line can be added to the bottom surface to make it easier to distinguish the bottom from fish and structure.

A-Scope


The A-scope is a display of real-time echoes as they appear on the panel. The strength of the actual echo is indicated by both width and color intensity.

Zoom bars


The zoom bars shows the range that is magnified on a split panel with zoom view.

Fish ID


You can select how you want the echoes to appear on the screen. You can also select if you want to be notified by a beep when a fish ID appear on the panel.



Traditional fish echoes




Fish symbols



Fish symbols and depth indication

→ **Note:** Not all fish symbols are actual fish.

Echosounder settings



Echosounder source

If you have more than one echosounder on your network, you can select which sounder to be the preferred source on this Zeus² unit.

Network echosounder

You can share the echosounder connected to this Zeus² unit on the network.

For more information about how to setup echosounders, refer to the separate Zeus² Installation manual.

Overlay downscan

When a StructureScan unit is connected to your Zeus² system, you can overlay DownScan images on the regular echo image.

When activated, the echosounder menu will expand to include basic StructureScan options.

View echosounder recording

Used to view internally stored echosounder recordings.

The log file is displayed as a paused image, and you control the scrolling and display from the menu.

You can use the cursor on the image, measure distance and set view options as on a live echosounder image. If more than one channel was recorded in the selected echosounder file, you can select which channel to display.

You exit the view function by selecting the **X** in the upper right corner.

Search depth

Noise may cause the echosounder to search for unrealistic depths.

By setting the search depth manually the system will only display echoes received from objects within the set depth range.

Installation

Used for echosounder installation and setup. See the separate Zeus²Installation manual.

12

StructureScan™

StructureScan HD™ uses high frequencies to provide a high resolution, picture-like image of the seabed.

StructureScan™ provides a 150 m (480 ft) wide coverage in high detail with SideScan, while the DownScan™ provides picture perfect images of structure and fish directly below your boat, down to 90 m (300 ft).


StructureScan™ is not integrated on Zeus² units. You must have a compatible external StructureScan module available on the network to use the StructureScan features.

The StructureScan™ image

The view

The StructureScan panel can be set up as a traditional downscan image, or showing left/right side scanning.

The DownScan image can also be added as an overlay to the traditional Echosounder image.



Key	Description
1	Depth
2	Temperature
3	Frequency
4	Bottom
5	Zoom (downscan) / Range (sidescan) icons
6	Range scale

Zooming the StructureScan image

You zoom a StructureScan image by:

- turning the rotary knob (when the cursor not is active)
- using the panel zoom icons
- by pinching or spreading on the screen

Zoom level is shown on the upper left side of the panel.

Using the cursor on the StructureScan™ panel

The cursor is by default not shown on the StructureScan image.

When you position the cursor, the cursor information window and the history bar will be activated. On a SideScan image the left/right distance from the vessel to the cursor are shown at the cursor position. On a DownScan image the depth will be shown at cursor position.


To remove the cursor and cursor elements from the panel, press **X** key or select the **Clear cursor** option.

GoTo cursor

You start navigating to a selected position on the image by positioning the cursor on the panel, then using the go to cursor option in the menu.

The Cursor assist function

When using a touch screen, the cursor assist function allows for fine tuning and precision placement of the cursor without covering details with your finger.



Press and hold your finger on the screen to switch the cursor symbol to a selection circle, appearing above your finger.

Without removing your finger from the screen, drag the selection circle over the desired item to display item information.

When you remove your finger from the screen the cursor reverts to normal cursor operation.

Measuring distance

The cursor can be used to measure the distance between the position of two observations on the image.

It is easier to use the measuring function when the image is paused.

1. Position the cursor on the point from where you want to measure the distance
2. Start the measuring function from the menu
3. Position the cursor on the second measuring point
 - A line will be drawn between the measuring points, and the distance will be listed in the Information window
4. Continue selecting new measuring points if required

You can use the menu to re-position the start point and the end point as long as the measuring function is active.

When you select **Finish measuring** or press the **X** key, the image will resume to normal scrolling.

Saving waypoints

You can save a waypoint at a selected location by positioning the cursor on the panel, then selecting the new waypoint option in the menu.

If your unit has a **MARK** key, you can press this key to immediately save a waypoint. If the cursor is active the waypoint will be saved at the cursor position. If the cursor is not active the waypoint will be saved at your vessel's position.

Viewing StructureScan™ history

Whenever the cursor is active on a StructureScan panel, the scroll bar is shown at the bottom of the panel. The scroll bar shows the image you are currently viewing in relation to the total StructureScan image history stored.

Depending of the view selected, the scroll bar is on the far right side (DownScan) or at the bottom of the screen (SideScan).

You can pan the image history by dragging up/down (SideScan) or left/right DownScan.

To resume normal StructureScan scrolling, press **Clear cursor**.

Setting up the StructureScan image

Range

The range setting determines the water depth that is visible on the screen.

Auto range

When the range is set to Auto the system will automatically set the range depending on the water depth.

Preset range levels

You can select between several preset range levels.

Custom range

This option allows you to manually set both upper and lower range limits.

The StructureScan panel can be set up as a single view, or with split view where the left and the right side presents different images.

StructureScan frequencies

StructureScan supports two frequencies. 455 kHz is ideal for greater depth penetration and while 800 kHz provides better definition especially at shallower depths.

Contrast

The contrast determines the brightness ratio between light and dark areas of the screen. This makes it easier to distinguish object from the background.

To adjust the contrast setting:

1. Select the contrast icon or activate the contrast option in the menu
 - The color adjustment bar is displayed
2. Drag the bar or use the rotary knob to set the value

Palettes

You can select between several display palettes optimized for a variety of fishing conditions.

Pausing the StructureScan image

You can pause the StructureScan image, allowing you to examine the structures and other images in more depth and detail.

This function is useful when you need to position a waypoint exactly on the StructureScan image, and if you are using the cursor to measure a distance between 2 elements on the image.

Advanced StructureScan settings

TVG

The TVG (Time Variable Gain) option compensate for distance to the object, making echoes from equal sized objects appear with the same size on the echosounder image.

Flipping the Structure image left/right

If required, the left/right SideScanning images can be flipped to match the corresponding side of your vessel.

Range Lines

Range lines can be added to the image to make it easier to estimate depth (Downscan) and distance (SideScan).

Recording StructureScan data

You can record StructureScan data and save the file internally in the Zeus² unit, or onto an SD card as described in "*Recording echosounder data*" on page 67.


13

StructureMap

The StructureMap™ feature overlays SideScan images from a StructureScan source on the map. This makes it easier to visualize the underwater environment in relation to your position, and aids in interpreting SideScan images.

The StructureMap image

The example below shows a chart panel with Structure overlay, combined with a traditional SideScan panel.



You move around in the chart as usual when you have a Structure overlay;

- zoom the chart and the scanned image by turning the rotary knob, by using the zoom icons, or by using pinch and spread gesture
 - move the chart to view the scanned image by dragging your finger in the selected direction
- Pressing the **X** key or selecting the **Clear cursor** option will remove the cursor from the panel, and the chart center will be positioned at the vessel.

Activating Structure overlay

1. Turn on Structure overlay from the chart menu
 - The chart menu will be increased to show Structure options
 - Structure data will start to appear on the chart screen as soon as Structure overlay is enabled
 2. Select Structure source
 - Live data is default
- **Note:** Structure overlay can also be activated by selecting a saved StructureMap file in the files browser.

StructureMap sources

Two sources can be used to overlay Structure logs on the charts;

- Live data, used when StructureScan data is available on the Zeus² system
- Saved files. These are recorded StructureScan (*.sl2) data that are converted to StructureMap (*.smf) format. Saved *.smf files can be used on Zeus² units even if no StructureScan units are connected.

Live source

When live data is selected the SideScan imaging history is displayed as a trail behind the vessel icon. The length of this trail will vary depending on available memory in the unit and range settings. As the memory fills up the oldest data will automatically be deleted as new data is added. When increasing the search range the ping speed of the StructureScan transducer is reduced, but the width and the length of the image history will be increased.

- **Note:** Live mode does not save any data. If the unit is turned off, all recent data is lost.

Saved files

When Saved files are selected, the StructureMap file is overlaid on the map based on position information in the file.

If the chart scale is large, the StructureMap area will be indicated with a boundary box until the scale is large enough to show Structure details.

Saved mode is used to review and examine StructureMap files, and to position the vessel on specific points of interest on a previous scanned area.

- **Note:** When saved files are used as source, the Zeus² displays all StructureMap files found on the SD card and in the system's internal memory. If there is more than one StructureMap of the same area, the images will overlap and clutter the chart. If several logs of the same area are required, the maps should be put on separate SD cards.

StructureMap tips

- To get a picture of taller structure (a wreck, etc) — don't drive over it. Steer the boat so the structure will be on the left or right side of your boat
- Don't use Autorange when using SideScan. Set your structure range to a significantly greater level (two-to-three times) than the water depth to ensure a complete scan and to maximize conversion accuracy
- Don't overlap history trails when conducting a side-by-side scan of an area

Recording StructureScan data

StructureScan data can be recorded from a chart panel with Structure overlay enabled.

StructureScan recordings can also be started from a StructureScan panel.

When StructureScan data is being recorded, there will be a flashing red symbol and a message will appear periodically at the bottom of the screen.

- **Note:** The message includes information about file size. Keep the size of your sonar logs to 100MB or less to allow for faster file conversion.

The sounder recording is stopped by re-selecting the record function.

Converting StructureScan data to StructureMap format

A StructureScan log file (.sl2) is converted to StructureMap format (.smf) after recording from the recording dialog, or from the files browser.

You can create standard or high resolution files. High resolution .smf files capture more detail, but take longer to convert and are larger than standard resolution files.

To save disc space it is recommended to remove the StructureScan (*.sl2) files after conversion.

Using StructureMap with mapping cards

StructureMap allows you to maintain full chart capability and can be used with embedded cartography as well as Navionics, Insight and other third-party charting cards compatible with the Zeus² systems.

When using StructureMap with mapping cards, copy the StructureMap (.smf) files to the unit's internal memory. We recommend keeping copies of StructureMap files on external SD cards.

Structure options

You adjust the StructureMap settings from the Structure options menu. The menu is available when Structure overlay is enabled.

Not all options are available when saved StructureMap files are used as source. Unavailable options are greyed.

Range	Sets the search range
Transparency	Sets the opaqueness of the Structure overlay. With minimum transparency settings the chart details will be almost hidden by the StructureMap overlay
Palette	Selects Structure palette
Contrast	Determines the brightness ratio between light and dark areas of the screen.
Water column	Shows/hides the water column in Live mode. If turned OFF schools of bait fish might not be seen on the SideScan image. If turned ON the accuracy of the SideScan image on the map might be affected by the water depth.
Frequency	Sets the transducer frequency used by the unit. 800 kHz offers the best resolution, while 455 kHz has greater depth and range coverage
Noise rejection	Filters the signal interference and reduces the on-screen clutter
Clear live history	Clears existing live mode history trails from the screen and begins showing only the most current data
Record data	Records StructureScan data
Source	Selects StructureMap source

14

AIS


If an NAIS400, an AI50 or a NMEA 2000 VHF that can do AIS (Automatic Identification System) is connected to the Zeus² system, any targets detected by this devices can be displayed and tracked. You can also see messages and position for DSC transmitting devices within range.

AIS targets can be displayed as overlay on radar and chart images, making this feature an important tool for safe travelling and collision avoidance.

You can define alarms to notify you if an AIS target gets too close or if the target is lost.



AIS vessels on a chart panel



AIS vessels on a radar panel

AIS target symbols

The Zeus² system use the AIS target symbols shown below:


Symbol	Description	
	Sleeping AIS target (not moving or at anchor).	
	Moving and safe AIS target with course extension line.	
	Dangerous AIS target, illustrated with bold line.	A target is defined as dangerous based on the CPA and TCPA settings. Refer "Defining dangerous vessels" on page 45.
	Lost AIS target.	When no signals have been received within a time limit a target will be defined as lost. The target symbol represents the last valid position of the target before the reception of data was lost.
	Selected AIS target, activated by selecting a target symbol.	The target will return to default target symbol when the cursor is removed from the symbol.

Viewing information about AIS targets

Searching for AIS items

You can search for AIS targets from any panel by using **Find** option in the Tools panel.



From a chart panel you can search for AIS targets by using the **Find** option in the menu. If the cursor is active, the system will search for vessels around cursor position. Without an active cursor the system will search for vessels around your vessel's position.



Viewing information about single AIS targets

When you select an AIS icon on the chart or radar panel the symbol will change to Selected target symbol, and the vessel name will be displayed.

You can display detailed information for a target by selecting the AIS pop-up, or from the menu when the target is selected.



AIS information on radar panels

The radar data bar includes information on up to 3 AIS targets.

The targets are listed with the closest target on top, and are color coded to indicate target status.


AIS VESSEL				
SIM VESSEL A safe				
SOG	15.0	kn	COG	271 °M
CPA	0.31	NM	TCPA	0:00:12
RNG	0.32	NM	BRG	9 °M
AIS VESSEL				
SIM VESSEL B safe				
SOG	20.0	kn	COG	271 °M
CPA	-	NM	TCPA	-
RNG	0.42	NM	BRG	324 °M
AIS VESSEL				
SIM VESSEL E safe				
SOG	0.0	kn	COG	006 °M
CPA	0.81	NM	TCPA	0:00:09
RNG	0.81	NM	BRG	269 °M

Calling an AIS vessel from the Zeus²

If the Zeus² system includes a VHF radio supporting DSC (Digital Select Calling) calls over NMEA 2000, you can initiate a DSC call to that vessel from the Zeus².

The call option will be available in the **AIS Vessel Details** dialog, and in the **Vessel** status dialog activated from the **Tools** panel.

From the **Call** dialog you can select to change channel or cancel the call. The **Call** dialog will be closed when the connection is established.



AIS SART

When an AIS SART (Search And Rescue beacon) is activated, it starts transmitting its position and identification data. This data is received by your AIS device.

If your AIS receiver is not compliant with AIS SART, it interprets the received AIS SART data as a signal from a standard AIS transmitter. An icon is positioned on the chart, but this icon is an AIS vessel icon.

If your AIS receiver is compliant with AIS SART, the following take place when AIS SART data is received:

- An AIS SART icon is located on the chart in the position received from the AIS SART
- An alarm message is displayed

If you have enabled the siren, the alarm message will be followed by an audible alarm.

→ **Note:** The icon will be green if the received AIS SART data is a test and not an active message.



AIS SART alarm message

When data is received from an AIS SART, an alarm message is displayed on the Zeus². This message includes the AIS SART's unique MMSI number, its position and its distance and bearing from your vessel. You have three options:



1. Ignore the alarm
 - The alarm is muted and the message closed. The alarm will not reappear

→ **Note:** If you ignore the alarm, the AIS SART icon remains visible on your chart, and the AIS SART remains in the Vessels list.


If the AIS stops receiving the AIS SART message, the AIS SART remains in the Vessels list for 10 minutes after it receives the last signal.

2. Save the waypoint

- The waypoint is saved to your waypoint list. This waypoint name will be prefixed with MOB AIS SART - followed by the unique MMSI number of the SART. e.g. MOB AIS SART - 12345678.
3. Activate the MOB function
- The display switches to a zoomed chart panel, centered on the AIS SART position
 - The Zeus² creates an active route to the AIS SART position
- **Note:** If the MOB function is already active, this will be terminated and replaced by the new route towards the AIS SART position!
- If you select the AIS SART icon on the chart you will see the AIS MOB details.


Vessel alarms

You can define several alarms to alert you if a target shows up within predefined range limits, or if a previously identified target is lost.



Alarm ID	Description
Dangerous vessel	Controls whether an alarm shall be activated when a vessel comes within the predefined CPA or TCPA. See “Defining dangerous vessels” on page 45.
AIS vessel lost	Sets the range for lost vessels. If a vessel is lost within the set range this will trigger an alarm → Note: The check box controls whether the alarm pop-up box is displayed and if the siren will sound. The CPA and TCPA defines when a vessel is dangerous regardless of the enabled/disabled state.
Vessel message	Controls whether an alarm shall be activated when a message is received from an AIS target

Vessel settings



Your vessel's MMSI number

You need to have your own MMSI (Maritime Mobile Service Identity) number entered in the Zeus² system to be able to receive addressed messages from AIS and DSC vessels.

It is also important to have the MMSI number entered to avoid seeing your own vessel as an AIS target on the chart.

→ **Note:** The Vessel message option in the alarm settings must be toggled on if any MMSI message shall be displayed.


Icon filters

All targets are by default shown on the panel if an AIS device is connected to the Zeus² system.

You can select not to show any targets, or to filter the icons based on security settings, distance and vessel speed.




Extension lines



The length of the extension lines for your vessel and for other vessels can be set by the user.

- A: Heading
- B: Course Over Ground (COG)

The length of the extension lines is either set as a fixed distance, or to indicate the distance the vessel will move in the selected time period. If no options are ticked on for **This vessel** then no extension lines will be shown for your vessel.




For own vessel heading information is read from active heading sensor, and COG information is as received from the active GPS.

For other vessels COG data is included in the message received from the AIS system.

Defining dangerous vessels

You can define an invisible guard zone around your vessel. When a target comes within this distance from your vessel, the symbol will change to the “dangerous” target symbol. An alarm will be triggered if activated in the Alarm settings panel.



Speed and course indication

The extension line can be used to indicate speed and course for targets; either as absolute (true) motion in the chart or relative to your vessel.

Different line style is used on the extension lines to indicate motion as shown below.



AIS vessels shown with Absolute motion



AIS vessels shown with Relative motion

AIS icon orientation

Sets the orientation of the AIS icon; either based on heading or COG information.

15

Instrument panels

The instrument panels consists of multiple gauges - analog, digital and bar - that can be customized to display selected data. The instrument panel displays data on dashboards, and you can define up to ten dashboards within the instrument panel.

→ **Note:** To include fuel/engine information, engine and tank information has to be configured from the Settings panel.

Dashboards

A set of different dashboard layouts are predefined to display gauges showing information about vessel, navigation information and angler requirement.

You switch between the panel's dashboards by selecting the left and right side of the panel. You can also select the dashboard from the menu.



→ **Note:** Additional dashboards can be activated from the menu if other systems (i.e. CZone) are present on the network.

Customizing the Instrument panel

You can customize the Instrument panel by changing the data for each of the gauges in the dashboard, by changing the dashboard layout, and by adding new dashboards. You can also set limits of analog gauges.

All edit options are available from the Instrument panel menu.

Available editing options will depend on which data sources that are connected to your system.

Edit a dashboard

Activate the dashboard you want to edit, then;

1. Activate the menu
2. Select the edit option
3. Select the gauge you want to change. Selected gauge is indicated with a blue background
4. Select information to be display, limits and eventually change the source for the information
5. Save your changes by selecting the save option in the menu

16

Audio


If a SonicHub server or a FUSION marine entertainment system is connected to the NMEA 2000 network, you can use the Zeus² to control and customize the audio solution on your vessel.

When connected to a WM-2 or WM-3 Satellite module you can subscribe and include Sirius™ audio on your Zeus² system. You can also connect a Sirius radio via a FUSION system. Sirius™ audio and weather service covers inland US waters and coastal areas into the Atlantic and Pacific oceans, Gulf of Mexico and the Caribbean Sea. The Sirius™ audio products received vary depending on your selected subscription package. For more information refer to www.sirius.com.

Before you can start using your audio equipment, it must be installed according to the Zeus² Installation manual and the documentation included with the audio device.

Enabling audio


Compatible audio device connected to the NMEA 2000 network should automatically be identified by the Zeus². If not, enable the feature from the **Advanced Settings** dialog.



The Audio panel

You activate the audio panel by activating the audio tile in the Instrument bar.

The control buttons, tools and options vary from one audio source to another as described later in this chapter.









Key	Description
1	Audio source
2	Audio control buttons
3	Audio tile
4	Audio tools

Audio control buttons

Icon	Tuner	VHF	DVD	Playback
	Select to display the list of available sources			
	Select to select previous/next frequency Press and hold to tune in a channel		Select to rewind/play fast forward	Select to select previous/next track
	Select to select next/previous favourite channel		N/A	N/A
	N/A	N/A	Select to start	
	N/A	N/A	Select to pause playback	
	Select to display the volume slider			

Audio tools

Icon	Tuner	VHF	Playback
	Signal strength	N/A	N/A
	N/A	N/A	Select to toggle on/off repeat function. The icon is colored when the function is active.
	N/A	N/A	Select to toggle on/off shuffle mode. The icon is colored when the function is active.
	Select to display menus used for settings up zones and master control		
	Select to display the favourite stations for the tuner	Select to display the favourite channels for the VHF	Select to display the native menu for active source
	Select to display optional settings for active source		

Setting up the audio system

The speakers

Speaker zones

The Zeus² can be set up to control different audio zones. Number of zones depends on the audio server connected to your Zeus² system.

You can adjust balance, volume and volume limit settings individually for each zone. Adjustments to the bass and treble settings will alter all zones.

Master volume control

By default the volume for all speaker zones are adjusted when you adjust the volume on the Zeus² unit. You can define which zones shall be altered when you increase/decrease the volume from the Zeus² unit.

Selecting tuner region

Before playing FM or AM radio and before using a VHF radio you must select the appropriate region for your location.

Detaching Sirius from the AUX source

If a Sirius radio is connected to the FUSION radio/server, the AUX source will be automatically attached to the Sirius feed. **Sirius** will then appear in the source list when the FUSION server is active.

To use the AUX source for a different device, the Sirius must be detached from the AUX source.

→ **Note:** To use SiriusXM an optional SiriusXM tuner must be connected to the FUSION server.

Operating the audio system

1. Select the Audio tile in the Instrument bar to activate the Audio overlay
2. Select the options icon and select the audio server
3. Select the source icon to select the audio source
 - Number of sources depends on active audio server
4. Use the panel buttons to control your audio system.

Refer to the overview of audio control buttons and tools previously in this chapter.

For available options and features for the audio equipment, refer to the documentation following the audio equipment.

Favourite channels

When a tuner or VHF channel is tuned in, you can add the channel to your favourite list. The favourite channels can be viewed, selected and deleted from within the Favourite list.

You page through favourite channels by using the up/down audio panel buttons.

Using Sirius radio (North America only)

Channels list

The channels list displays all available Sirius channels, whether or not you have a subscription for the channel.

Favorite list

You can create a list of your favorite Sirius channels from within the channels list. You will not be able to add unsubscribed channels.

Locking channels

You can lock selected Sirius channels from being broadcasted unless an unlock code is entered.

When the function is activated, a 4 digit code must be entered before the locking is activated.

The same code must be entered before a locked channel can be released.

17

Weather





The Zeus² includes weather functionality that allows the user to view forecast data overlaid on the chart. This helps gaining a clear understanding of the weather conditions that are likely to appear.

Zeus² supports weater data in GRIB format, available for download from various weather service suppliers. The system also supports weather data from SIRIUS Marine Weather Service. This service is available only in North America.


Wind barbs

The rotation of the wind barbs indicate the relative wind direction, with the tail showing the direction the wind is coming from. In the graphics below the wind comes f rom from northwest.

Wind speed is indicated by a combination of small and large barbs at the end of the wind tail.

	Zero knots / Indeterminate wind direction
	Small barb = 5 knots
	Large barb = 10 knots
	Arrow barb = 50 knots

If a combination of 5 and 10 knot barbs are shown on a tail then these will need to be added together to give you the total wind speed. The example below shows 3 x large barb + 1 x small barb = 35 knots, and 60 knots indicated with 1 x arrow barb + 1 x large barb.



Wind speed: 35 knots



Wind speed: 60 knots

GRIB weather


A GRIB file contains forecast information for a set number of days. It is possible to animate the weather data which shows how weather systems are developing.

Importing GRIB data

The downloaded GRIB data must be imported into memory before it can be used. The file can be imported from any location that can be seen in the file explorer.

→ **Note:** GRIB data that is imported from an SD card will not be saved in the Zeus². The data will be lost when new GRIB data is imported.

Select the GRIB file to import the data.




The GRIB weather display

Imported GRIB weather data can be displayed as an overlay on your chart panel.

When the GRIB weather overlay is selected, the chart menu will increase to show GRIB weather options. From this menu you can select which weather symbols you want to display, set the distance between the barbs, and you can adjust the opaqueness of the weather symbols.

From this menu you can also animate the weather forecast as described later in this chapter.



Key	Description
1	Wind barbs
2	Pressure contours
3	GRIB information window

GRIB information window

The GRIB information window shows the date and time for the GRIB weather forecast, and the selected forecast time in brackets. A negative value in the brackets indicates historic weather data.

If you select a position on the chart the information window will expand to include weather details for the selected position.

Animating GRIB weather forecast

The GRIB data contains forecast information for a set number of days. It is possible to animate the weather data and to show the predicted forecast for a specific time and date. The time scales will vary depending on the file you are using.

The time shift is shown in brackets in the GRIB information window. The time will be relative to the current time as provided by a GPS device connected to the Zeus².

Select time and animation speed from the menu.

SiriusXM™ weather

When connected to a Navico Weather module, you can subscribe and include Sirius™ audio and Sirius™ Marine Weather Service on your Zeus² system (North America only).

Sirius™ audio and weather service covers inland US waters and coastal areas into the Atlantic and Pacific oceans, Gulf of Mexico and the Caribbean Sea.

The audio and weather products received vary depending on your selected subscription package. For more information refer to www.siriusxm.com/marineweather

Sirius status panel

When the weather module is connected to the system, you will get access to the Sirius™ status panel.


Signal strength is indicated as 1/3 (weak), 2/3 (good) or 3/3 (preferred).

The ESN shows the electronic serial number for the WM-2 module.

Sirius weather display

The Sirius weather can be displayed as an overlay on your chart panel.

When weather overlay is selected, the chart menu will increase to show the available weather options.



Key	Description
1	Precipitation color shading
2	City forecast icon
3	Wind barb
4	Storm icon
5	SST color bar
6	SST color shading

Use the Sirius weather option menu to select which weather symbology that should be displayed and how they should appear on the chart panel.

Precipitation

Shades of color are used to show precipitation type and intensity. Darkest color indicates highest intensity.

Precipitation type	Color code
Rain	From light green (light rain) - yellow - orange - to dark red (heavy rain)
Snow	Blue
Mixed	Pink

Sea Surface Temperature (SST)

Can be shown as color shading or text.

When color coding is selected, the SST color bar will be shown on the left side of the display. You can define which temperature range that shall be color coded as described later in this section.










Wave indication

Colors are used to indicate forecasted wave height. Dark red indicate the highest waves, while blue are used for the lowest.

You can define which height range shall be color coded as described later in this section.

Weather icons

Several weather icons are available to show current or predicted weather conditions. You can select an icon to display detailed weather information.

Icon	Description
	City forecast
	Surface observation
	Tropical storm tracking; past (grey) - present (red) - future (yellow)
	Hurricane (category 1-5) tracking; past (grey) - present (red) - future (yellow)
	Tropical disturbance/depression tracking; past (grey) - present (red) - future (yellow)
	Storm attributes
	Lightning
	Watch box location and warning
	Marine zone location

Color Shading

You can define the sea surface temperature range and wave height color coding.

The temperature above warm and below cool values will be displayed as progressively darker red and darker blue.

Waves higher than the maximum value will be indicated with progressively darker red. Waves lower than the minimum value will not be color coded.

Marine zones

Sirius™ service includes access to weather reports for all U.S. Marine Zones, with the exception of the high seas zones.

You can setup the system to read the forecast for a selected area.

Select the selected zone, and use the menu to confirm your selection.

Tropical statements

You can read tropical statements including information about tropical weather conditions. These statements are available for the entire Atlantic and the Eastern Pacific.

Showing Sirius weather details

When you select a shaded weather area, available information will be shown in the cursor window.

If pop-up is enabled, you can select a weather icon to display the identity of the observation. If you select the pop-up, detailed information about the observation is displayed. You can also display the detailed information from the menu when the weather icon is selected.

Animating Sirius™ weather graphics

The Zeus² records the weather information you have turned on, and this information can be used to animate past or future weather conditions. The amount of information available in the system depends on the amount of weather activity; the more complex it is, the less time will be available for animation.

You can animate the past or the future, depending on which weather view you have turned on:

- if the precipitation overlay was turned on, you can animate for the past and only assume weather conditions in the immediate future.
- if the colored wave height overlay was turned on, you can animate the future (the predictions).


When activated, the time for the current graphic animation will be displayed in the lower left corner of the chart panel.

Weather alarms

You can setup the lightning or storm alarms to be within a certain range of your vessel.

You can also get an alarm as a severe weather forecast alarm issued for your chosen marine zone.

A watchbox is defined by the National Weather Service. When the alarm is turned on you will get an alarm when your vessel is inside or is entering into a watchbox.



18

Video

The video function allows you to view videos or camera sources on your Zeus².

→ **Note:** The video images will not be shared via the network. You can only view the video on the unit connected to the video source.


If a FLIR camera is available on the Ethernet network, you can display the video and control the camera from the Zeus².

For information about how to connect the camera, see the separate Zeus² Installation manual.

The Video panel

A video panel can be set up as a single panel, or as one of the panels on a multiple panel page.

The video image will be proportionally scaled to fit into the video panel. Area not covered by the image will be colored black.



Setting up the video panel

Video source

Zeus² supports two video input channels. You can select to view one channel only, or to cycle the image between available video cameras.

The cycle period can be set from 5 to 120 seconds.

Video standard

Zeus² supports NTSC and PAL video. The two channels are set up individually. Check the local video standard or the standard of your cameras.

Adjusting the video image

You can optimize the video display by adjusting the video image settings. The settings are adjusted individually for each video source. Default for all settings: 50%.



FLIR camera control

When the connection is established to a FLIR camera, the menu will change to include access to FLIR camera controls.

- **Note:** You can take over camera control from any Zeus² connected to the Ethernet network.

Establishing connection with the FLIR video camera

When a video panel is active, the Zeus² will automatically recognize a Flir camera if this is available on the network.

- **Note:** When there is DHCP server present on the Ethernet network, FLIR camera will need to be configured and set to have Static IP Address before the connection can be established. For instructions on how to configure your specific FLIR camera model please refer to FLIR documentation.

- **Note:** Only one FLIR camera can be connected to the Ethernet network at a time.

When you activate a video panel, the system will start searching the network for a FLIR camera.

If the connection later is lost, this will be indicated by a panel key. Select this key to reestablish the connection.

When the connection is established the menu will change to include access to FLIR camera control.

- **Note:** You can take over camera control from any Zeus² unit connected to the Ethernet network.

Panning and tilting the FLIR camera

When the connection to the FLIR camera is established, pan and tilt panel buttons appear on the video panel. The left and right arrow buttons control the camera's pan, while the up and down arrow buttons tilt the camera.

Press one of the arrow buttons on the panel to control the camera. The camera will move as long as you press the button.

Zooming the FLIR video image

You zoom the video image by using the zoom panel buttons.

There are two different zoom options available, depending on selected FLIR camera source option.

Digital zoom

Only available when the camera is in Infrared mode.

In this mode the zoom is represented in levels (0, 2 and 4 times zoom). Each press on a zoom button will increment or decrement the zoom level.

Optical zoom

Available in daylight mode.

In this mode the camera will zoom as long as you press a zoom panel button.

The FLIR camera source options

The FLIR camera includes both daylight and infrared video sources.

When the infrared source is selected, the following options are available:

Toggle color scheme	Cycles through FLIR's video output color scheme. Each of these schemes maps a different color to a different temperature
Toggle polarity	Inverts the color scheme. For example, instead of: White = Hot and Black = Cold, it will become Black = Hot and White = Cold

The FLIR camera's home position

You can set the current pan and tilt position as the camera's home position.

You can later quickly return to this camera position.

19

Alarms

Alarm system

The system will continuously check for dangerous situations and system faults while the system is running. When an alarm situation occurs, an alarm message pops up on the screen. An alarm icon is displayed in the status bar, and the status bar pulses the color of the alarm.

If you have enabled the siren, the alarm message will be followed by an audible alarm, and the switch for external alarm will go active.

The alarm is recorded in the alarm listing so that you can see the details and take the appropriate corrective action.


Type of messages

The messages are classified according to how the reported situation will affect your vessel. The following color codes are used:

Color	Importance
Red	Critical
Orange	Important
Yellow	Standard
Blue	Warning
Green	Light warning


Single alarms

A single alarm is displayed with the name of the alarm as the title, and with details for the alarm.



Multiple alarms

If more than one alarm is activated simultaneously, the alarm message will display a list of up to 3 alarms. The alarms are listed in the order they occur with the alarm activated first at the top. The remaining alarms are available in the Alarms dialog.



Acknowledging a message


The following options are available in the alarm dialog for acknowledging a message:

Option	Result
Close	Sets the alarm state to acknowledged, meaning that you are aware of the alarm condition. The siren / buzzer will stop and the alarm dialog will be removed. The alarm will, however, remain active in the alarm listing until the reason for the alarm has been removed.
Disable	Disables the current alarm setting. The alarm will not show again unless you turn it back on in the Alarms dialog.


There is no time-out on the alarm message or siren. They remain until you acknowledge the alarm or until the reason for the alarm is removed.

Alarms dialog

All alarms are setup in the Alarms Settings dialog.



The alarm dialogs can also be activated from the Tools panel. The alarm dialogs includes information about active alarms and alarm history.



20

Tools

The Tools panel includes by default icons used for accessing options and tools that are not specific to any panel.

When external equipment is integrated to the Zeus², new icons might be added to the Tools panel. These icons are used for accessing the external equipment's features.

Waypoints/routes/tracks

List of waypoints, routes and tracks with details.

Select the waypoint, route or track you wish to edit or delete.

Tides

Displays tide information for the tide station nearest to your vessel.

Select the arrow panel buttons to change the date, or select the date field to access the calendar function.

Available tide stations can be selected from the menu.

Alarms

Active alarms

List of active alarms.

Alarm history

List of all alarms with time stamp.

Alarm settings

List of all available alarm options in the system, with current settings.

Settings

Provides access to application and system settings.

Vessels

Status listing

List of all AIS, MARPA, and DSC vessels with available information.

Message listing

List of all messages received from other AIS vessels with time stamp.

Sun/Moon

Displays sunrise, sunset, moonrise and moonset for a position based on entered date and the position's latitude/longitude.

Trip calculator

Trip 1 / Trip 2

Displays voyage and engine information, with reset option for all data fields.

Today

Displays voyage and engine information for current date. All data fields are automatically reset when the date changes.

Files

File management system for files, waypoints, routes, tracks and settings.

Find


Search function for chart items.

21

Simulator

The simulation feature lets you see how the unit works in a stationary position and without being connected to radar, GPS etc.

Use the simulator to help you become familiar with your unit before using it out on the water.



When the simulator is toggled on this is indicated in the status bar.

Demo mode


In this mode the unit automatically runs through the main features of the product; it changes pages automatically, adjusts settings, opens menus etc.

If you tap on a touch screen or press a key when demo mode is running, the demonstration will pause. After a time-out period, demo mode will resume.

Simulator source files


You can select which data files to be used by the simulator.

A set of source files is included in your system, and you can import files by using an SD card inserted into the unit's card reader. You can also use your own recorded files in the simulator.



Advanced simulator settings

The Advanced simulator settings allows for manually controlling the emulator.



GPS source

Selects where the GPS data is generated from.

Speed, Course and Route

Used for manually entering values when GPS source is set to Simulated course or Simulated route. Otherwise, GPS data including speed and course comes from the selected source file.

Set start position

Moves the vessel to current cursor position.

→ **Note:** This option is only available when the GPS source is set to Simulated course.

Sailing

Opens dialog for selecting sail specific simulator data.

22

Maintenance

Preventive maintenance

The Zeus² unit does not contain any field serviceable components, therefore the operator is required to perform only a very limited amount of preventative maintenance.

It is recommended that you always fit the supplied protective sun cover when the unit is not in use.

Cleaning the display unit

The supplied cleaning cloth should be used to clean the screen, where possible. Use plenty of water to dissolve and take away salt remains. Crystallized salt may scratch the coating if using a damp cloth. Apply minimal pressure to the screen.

Where marks on the screen can't be removed by the cloth alone, use a 50/50 mixture of warm water and isopropyl alcohol to clean the screen. Avoid any contact with solvents (acetone, mineral turpentine etc.), or ammonia based cleaning products, as they may damage the anti-glare layer or plastics bezel.

To prevent UV damage to the plastic bezel, it is recommended that the sun cover be fitted when the unit is not in use for an extended period.

Cleaning the media port door

Clean the media port door regularly to avoid that salt crystallize on the surface, causing water to leak into the card slot.

Checking the keys

Make sure that no keys are stuck in the down position. If one is stuck, wiggle the key to free it back to normal.

Checking the connectors

The connectors should be checked by visual inspection only.


Push the connector plugs into the connector, if the connector plugs are equipped with a lock; ensure that this is in the correct position.

NMEA 0183 Data logging

All serial output sentences sent over the NMEA 0183 TCP connection are logged to an internal file. You can export and review this file for service and fault finding purposes.

The maximum file size is predefined. If you have added several other files to the system (file recordings, music, pictures, pdf files), this may reduce the allowed file size for the log file.

The system logs as much data as possible within the file size limitation, then it starts overwriting the oldest data.



Exporting the log file

The log file can be exported from the files browser.

When you select the Log database you are prompted to select a destination folder and filename. Once accepted the log file is written to the chosen location.

Software upgrades

The latest software for the Zeus² will be available for download from our website; bandg.com.

Detailed instructions for how to install the software will follow the upgrade files.


Backing up your system data

Waypoints, routes, tracks that you create are filed in your system. It is recommended to regularly copy these files and your system settings files as part of your back-up routine. The files can be copied to an SD card inserted in the card slot on the front of the unit.

Different output formats are available:

User Data File version 5	This is used to import and export waypoints and routes with a standardized universally unique identifier (UUID), which is very reliable and easy to use. The data includes such information as the time and date when a route was created etc.
User Data File version 4	This is best used when transferring data from one NS* system to another, since it contains all the extra bits of information these systems store about items.
User Data file version 3 (w/depth)	Should be used when transferring user data from an NS* system to a legacy Lowrance (LMS, LCX, etc)
User data file version 2 (no depth)	
GPX (GPS Exchange)	This is the format most used on the web that shares among most GPS systems in the world. Use this format if you are taking data to a competitors unit.
Northstar.dat (no Tracks)	Used to transfer data to a legacy Northstar device.

The graphics shows how to export waypoints, routes and tracks.



1. Select the files option from the home page
2. Select the data you want to export
3. Select the export option in the dialog
4. Select export format
5. Select destination folder
6. Enter name for exported file.



B&G



CE0980