

REPLACING GASKET ON BOMAR HATCHES AND PORTS

ADHESIVE BACKED GASKET

(part numbers P100-53, P100-51, P100-52, P3000-20, P3000-21, P3000-22)

1. Pull out old gasket and using a sharp metal object (knife, awl, narrow chisel) scrape out all old adhesive. It is critical that all the old adhesive be removed.
2. Wipe down the gasket area with Isopropyl Alcohol. Use only Isopropyl Alcohol.
3. Starting near a hinge, pull back tape cover and apply gasket. After gasket is installed around perimeter, carefully cut gasket to length forming a butt joint. Using any new tube of superglue, cement butt joint being careful not to get superglue on the lens. Allow glue to set for five minutes.
4. Carefully go back and apply pressure the entire gasket. This step is extremely important. Pressure is needed to assure proper adhesion of the tape.