


# WIPER CONTROL | W10, 12, 25, 38 & 50

# Installation Instructions

Before installation please read these instructions.



- Up to 2 or 3 motors
- Synchronized sweep
- Interval
- Slow speed
- Fast speed
- Washer output



#### **Function for switch**


- -One push to the on position will start all motors in synchronized interval.
- -One more push to momentary will run all motors in slow speed synchronized.
- -One more push will run all motors in fast speed synchronized.
- -One more push starts from interval and so on.
- -One long push from off to momentary will start one motor in interval (W1).
- -One more push will run one motor in slow speed.
- -One more push will run one motor in fast speed.
- -One more push starts one motor from interval and so on.


#### Washer:


When running, push switch to momentary more than one second and washer will start.

### Motor protection:


If motor runs too slow or stops, it will shut off if not reaching park position within 5 sec. Push switch to off and then to on, and motor will start again.











**Item no. Voltage** 532202 12/24 V 532203 12/24 V

Wipers Up to 2 Up to 3

## **Limited warranty**

- » Roca warrants the wiper control to be free from defective material and workmanship for a period of 3 years from the date of purchase.
- This warranty does not apply to failure or damage caused by improper installation, misuse, lightning strike or damage from a power surge.
- » If failure occurs during this period, return it to your dealer for repair or replacement.

Fits wiper motors: W10, W12, W25, W38 and W50

