

Setup

(**Compliance statements**

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Identifier: RAYGOFREEWIFI

Specifications

WIFI-1 features	
Marinised construction	IPX5
Wireless standards	802.11 b/g
Ethernet network ports	2
Automatic configuration	Plug-n-play
Power supply	12 V DC, 200 mA
Supported hotspot security	WPA-PSK, WPA2, WPE 64/128 bit encryption , TKIP encryption

References









www.simrad-yachting.com/gofree


For a list of supported features or to download the latest software for your MFD please visit::

Dimensional drawing



























→ *Note*: Graphics from iPad and App Store are examples only. Tablets and smartphones from other vendors can be used for controlling the MFD where relevant Apps are available.

Client mode

Connect WIFI-1 to a wireless hotspot


Connect the WIFI-1 to a wireless 802.11 b/g Internet hotspot to access the new and future Internet based features on your MFD such as the GoFree

- Note: GoFree apps on mobile devices will not work when WIFI-1 is connected to an Internet hotspot in client mode.
- → **Note:** Change back to GoFree access point mode at any time to resume using GoFree Apps. Changing between modes can take up to 2 minutes.



Select HOME or PAGES key





Quick disconnect from the Internet







Are you sure you wish to disconnect from the Wireless hotspot?

Disconnecting will switch the WIFI-1 back into access point mode.

Note: The WIFI-1 module will restart each time the mode is changed. The WIFI-1 will be off line for up to two minutes.





OR





Connecting to a wireless hotspot will switch your primary GoFree WIFI-1 Access Point from being Connecting to a wheress not spot win switch your primary dorrier wire-in Access Point From Deing at access point to being a wireless client.

Other wireless devices will no longer be able to connect to the network unless you have additional GoFree WIFI-1 Access Points on the network Please wait while the GoFree Wifi Access Point restarts.

Note: If a wireless hotspot was set to remember key and connect automatically and is in range. The WIFI-1 will connect to it automatically