


Subject: how to test a Wave antenna

1 - First of all check the fuse to see whether it blew. If using the multimeter to measure ohms, the reading should match (or nearly match) the one provided when you touched the two leads. If the fuse is blown, it will not read anything at all, or the meter will display O.L. depending on the brand and type of meter you are using.






2 - If the fuse is fine then check if there's power supplying the antenna. Unplug the cable from the antenna and check the 12V while the power inserter/splitter is powered up.



3 - If the antenna regularly gets the 12V then try both outputs by connecting the TV to Output 1 and then to Output 2.





NOTE

Don't forget that after having made the setup as explained in the manual you must scan for available channels with your TV, otherwise you won't see any signal displayed on the screen.